

Part No.	Description	Package Qauntity	2012 List Price
0002025	Seat, Inlet	1	3.74
0004001	Strainer	10	0.38
0004002	Strainer	10	0.40
0004003	Strainer	10	0.41
0004004	Strainer	10	0.53
0004005	Strainer	10	0.38
0004006	Strainer	10	0.52
0004008	Strainer	10	0.38
0004009	Strainer	10	0.47
0004010	Strainer	10	0.54
0004011	Strainer	10	0.54
0004032	Strainer	10	0.60
0004033	Strainer	10	0.60
0004034	Strainer	10	0.41
0005001	Plug, Welch	10	0.46
0005002	Plug, Welch	10	0.38
0005004	Plug, Welch	10	0.47
0005005	Plug, Welch	10	0.53
0005006	Plug, Welch	10	0.47
0005007	Plug, Welch	10	0.53
0005008	Plug, Welch	10	0.55
0005009	Plug, Welch	10	0.53
0005010	Plug, Welch	10	0.49
0005011	Plug, Welch	10	0.49
0005013	Plug, Welch	10	0.50
0005035	Plug, Welch	10	0.53
0005039	Plug, Welch	10	0.53
0005042	Plug, Welch	10	0.53
0005044	Plug, H Adjust Screw	10	0.53
0005047	Plug, Choke Shaft	10	0.53
0005054	Plug, Welch	10	0.53
0008004	Valve, Check	10	0.38
0009010	Retainer, Syringe	10	1.06
0009015	Retainer, Syringe	10	1.06
0009016	Retainer, Check Valve	10	1.06
0009017	Retainer, Shaft	10	0.60
0009022	Retainer	10	1.06
0009025	Retainer, Limiter	10	1.06
0009027	Retainer, Syringe	10	1.06
0009028	Retainer, Limiter	10	0.95
0009031	Retainer	10	1.37
0009034	Retainer		

0009063	Retainer	10	1.06
0009065	Retainer	10	1.06
0009068	Retainer, Spring		
0009082	Retainer, Syringe	10	1.06
0009083	Retainer, Plug Ball	10	1.06
0009088	Retainer, Spring	10	1.37
0011121	Shaft, Throttle	1	4.58
0011122	Shaft, Throttle	1	4.58
0011213	Shaft, Throttle	1	4.58
0012017	Lever, Throttle	5	0.65
0012023	Lever, Throttle	5	0.70
0012039	Lever, Throttle	5	1.66
0012042	Lever, Throttle	5	0.70
0012045	Lever, Throttle	5	0.83
0012046	Lever, Throttle	5	0.92
0012055	Lever, Throttle	5	0.70
0012064	Lever, Throttle	5	1.01
0012067	Lever, Throttle	5	0.83
0012071	Lever, Throttle	5	0.83
0012085	Lever, Throttle	5	0.83
0012089	Lever, Throttle	5	0.83
0012091	Lever, Throttle	5	0.83
0012092	Lever, Throttle	5	0.83
0012094	Lever, Throttle	5	0.83
0012095	Lever, Throttle	5	0.83
0012096	Lever, Throttle	5	1.01
0012099	Lever, Throttle	5	1.01
0012103	Lever, Throttle		
0012106	Lever, Throttle	5	0.83
0012109	Lever, Choke	5	0.83
0012132	Lever, Throttle	5	0.83
0012135	Lever, Throttle	5	0.83
0012137	Lever, Throttle	5	0.83
0012138	Lever, Throttle	5	0.79
0012139	Lever, Throttle	5	0.83
0012149	Discontinued		
0012151	Lever, Throttle	5	1.01
0012154	Lever, Throttle	5	1.01
0012157	Lever, Throttle		
0012161	Lever, Throttle	5	0.88
0012162	Lever, Throttle	5	0.88
0012163	Lever, Throttle	5	1.01
0012166	Lever, Throttle	5	0.88

0012171	Lever, Throttle	5	0.88
0012175	Lever, Throttle	5	0.88
0012179	Lever, Throttle	5	0.88
0012181	Lever, Throttle	5	0.88
0012182	Lever, Throttle	5	0.88
0012189	Lever, Throttle	5	0.88
0012193	Lever, Throttle	5	1.01
0012194	Lever, Throttle	5	1.01
0012196	Lever, Throttle	5	1.01
0012199	Lever, Throttle	5	0.88
0012200	Lever, Throttle		
0012208	Lever, Throttle	5	1.01
0012210	Lever, Throttle	5	0.88
0012224	Lever, Throttle	5	1.01
0012225	Lever, Throttle	5	1.01
0012233	Lever, Throttle	5	1.01
0012234	Lever, Throttle		
0012236	Lever, Throttle	5	1.01
0012238	Lever, Throttle	5	1.01
0012253	Lever, Throttle	5	1.01
0012256	Lever, Throttle	5	1.01
0012259	Lever, Throttle	5	1.01
0012261	Lever, Throttle	5	1.01
0012266	Lever, Throttle		
0012269	Lever, Throttle	5	1.01
0012275	Lever, Throttle	5	1.01
0012277	Lever, Throttle	5	1.01
0012278	Lever, Throttle	5	1.01
0012288	Lever, Throttle		
0012290	Lever, Throttle		
0012295	Lever, Throttle	5	1.01
0012296	Lever, Throttle	5	1.01
0012297	Lever, Throttle	5	1.01
0012298	Lever, Throttle		
0012304	Lever, Throttle		
0012306	Lever, Throttle		
0012310	Lever, Throttle	5	1.01
0012313	Lever, Throttle	5	1.01
0012314	Lever, Throttle		
0012316	Lever, Throttle	5	1.01
0012322	Lever, Throttle	5	1.01
0012336	Lever, Throttle	5	1.01
0012337	Lever, Throttle		

0012703	Lever, Throttle	5	1.01
0012704	Lever, Throttle	5	1.01
0013002	Spring, Throttle Return	10	0.52
0013005	Spring, Throttle Return	10	0.49
0013011	Spring, Throttle Return	10	0.55
0013012	Spring, Throttle Return	10	0.52
0013014	Spring, Throttle Return	10	0.55
0013015	Spring, Throttle Return	10	0.56
0013016	Spring, Throttle Return	10	0.54
0013017	Spring, Throttle Return	10	0.56
0013018	Spring, Throttle Return	10	0.56
0013019	Spring, Choke Return	10	0.56
0013020	Spring, Throttle Return	10	0.56
0013021	Spring, Choke Return	10	0.56
0013023	Spring, Throttle Return	10	0.67
0013024	Spring, Throttle Return	10	0.56
0013025	Spring, Choke Return	10	0.56
0013027	Spring, Throttle Return	10	0.59
0013028	Spring, Throttle Return	10	0.59
0013029	Spring, Throttle Return	10	0.59
0013030	Spring, Choke Return	10	0.72
0013031	Spring, Throttle Return	10	0.59
0013032	Spring, Choke Linkage	10	0.59
0013036	Spring, Throttle Return	10	0.56
0013037	Spring, Choke Return	10	0.56
0013038	Spring, Throttle Return	10	0.72
0013040	Spring, Throttle Return	10	0.72
0013041	Spring, Throttle Return	10	0.72
0013042	Spring, Throttle Return	10	0.59
0013043	Spring, Throttle Return	10	0.56
0013044	Spring, Throttle Return	10	0.72
0013065	Spring, Choke Return	10	0.72
0013066	Spring, Choke Return	10	0.72
0013067	Spring, Choke Return	10	0.72
0013068	Spring, Choke Return	10	0.72
0013071	Spring, Choke Return	10	0.70
0013072	Spring, Throttle Return	10	0.70
0013073	Spring, Detent	10	0.70
0013074	Spring, Detent	10	0.70
0013075	Spring, Throttle Return	10	0.70
0013076	Spring, Throttle Return	10	0.70
0013077	Spring, Choke Return	10	0.70
0013078	Spring, Throttle Return	10	0.56

0013079	Spring, Choke Return	10	0.70
0013080	Spring, Throttle Return	10	0.70
0013081	Spring, Throttle Return	10	0.70
0013082	Spring, Choke Return	10	0.70
0013083	Spring, Choke Return	10	0.70
0013085	Spring, Choke Return	10	0.70
0013086	Spring, Choke Return	10	0.70
0013087	Spring, Choke Return	10	0.70
0013088	Spring, Choke Return	10	0.70
0013089	Spring, Throttle Return	10	0.70
0013090	Spring, Choke Return	10	0.70
0013093	Spring, Choke Return	10	0.72
0013094	Spring, Airhead	10	0.71
0013095	Spring, Throttle Return	10	0.75
0013096	Spring, Choke Return	10	0.70
0013097	Spring, Airhead	10	0.70
0013099	Spring, Throttle Return	10	0.70
0013100	Spring, Airhead	10	0.70
0013101	Spring, Throttle Return	10	0.70
0013102	Spring, Choke Return	10	0.70
0013103	Spring, Choke Return	10	0.70
0013104	Spring, Throttle Return	10	0.70
0013105	Spring, Throttle Return	10	0.70
0013107	Spring, Throttle Return	10	0.71
0013108	Spring, Choke Return	10	0.70
0013109	Spring, Throttle Return	10	0.70
0013112	Spring, Choke Return	10	0.70
0013113	Spring, Airhead	10	0.70
0013114	Spring, Choke Return	10	0.70
0013115	Spring, Choke Return	10	0.70
0013116	Spring, Throttle Return	10	0.70
0013117	Spring, Throttle Return	10	0.70
0013118	Spring, Airhead	10	0.70
0013119	Spring, Throttle Return	10	0.70
0013120	Spring, Choke Return	10	0.70
0013121	Spring, Throttle Return	10	0.70
0013122	Spring, Lever Control	10	0.70
0013124	Spring, Choke Return	10	0.70
0013126	Spring, Choke Return	10	0.70
0013129	Spring, Throttle Return	10	0.70
0013130	Spring, Choke Return	10	0.70
0013136	Spring, Throttle Return	10	0.70
0013137	Spring, Throttle Return	10	0.70

0013138	Spring, Choke Return	10	0.70
0013139	Spring, Airhead	10	0.70
0013140	Spring, Throttle Return	10	0.70
0013141	Spring, Choke Return	10	0.70
0013142	Spring, Throttle Return	10	0.70
0013143	Spring, Choke Return	10	0.70
0013149	Spring, Choke Return	10	0.70
0013154	Spring, Throttle Return	10	0.70
0013701	Spring, Choke	10	0.70
0013703	Spring, Throttle Return	10	0.70
0013705	Spring, Choke Return	10	0.70
0013706	Spring, Throttle Return	10	0.70
0014002	Valve, Throttle	5	0.72
0014003	Valve, Throttle	5	0.87
0014004	Valve, Throttle	5	0.72
0014007	Valve, Throttle	5	0.72
0014008	Valve, Throttle	5	0.87
0014010	Valve, Throttle	5	0.90
0014015	Valve, Throttle	5	0.87
0014016	Valve, Throttle	5	1.02
0014018	Valve, Throttle	5	1.34
0014020	Valve, Throttle	5	0.92
0014023	Valve, Throttle	5	1.64
0014025	Valve, Throttle	5	1.38
0014026	Valve, Throttle	5	1.35
0014027	Valve, Throttle	5	1.30
0014028	Valve, Throttle	5	1.92
0014029	Valve, Throttle	5	1.34
0014030	Valve, Throttle	5	1.35
0014031	Valve, Throttle	5	1.21
0014032	Valve, Throttle	5	1.35
0014033	Valve, Throttle	5	1.21
0014035	Valve, Throttle	5	1.21
0014036	Valve, Throttle	5	1.35
0014037	Valve, Throttle	5	1.35
0014038	Valve, Throttle	5	1.35
0014040	Valve, Throttle	5	1.35
0014041	Valve, Throttle	5	1.35
0014044	Valve, Throttle	5	1.35
0014045	Valve, Throttle	5	1.35
0014047	Valve, Throttle	5	1.35
0014048	Valve, Throttle	5	1.35
0014049	Valve, Throttle	5	1.35

0014050	Valve, Throttle	5	1.70
0014053	Valve, Throttle	5	1.37
0014054	Valve, Throttle		
0014056	Valve, Throttle	5	1.92
0014057	Valve, Throttle	5	1.35
0014076	Valve, Throttle		
0014077	Valve, Throttle		
0014079	Valve, Throttle	5	1.67
0014080	Valve, Throttle	5	1.70
0014081	Valve, Throttle	5	1.70
0014082	Valve, Throttle	5	1.67
0014083	Valve, Throttle	5	1.64
0014084	Valve, Throttle	5	1.70
0014086	Valve, Throttle	5	1.70
0014087	Valve, Throttle	5	1.70
0014089	Valve, Throttle	5	1.70
0014090	Valve, Throttle		
0014091	Valve, Throttle	5	1.64
0014093	Valve, Throttle	5	1.70
0014094	Valve, Throttle	5	1.70
0014095	Valve, Throttle		
0014096	Valve, Throttle		
0014098	Valve, Throttle	5	1.70
0014099	Valve, Throttle		
0014102	Valve, Throttle	5	1.70
0014103	Valve, Throttle	5	1.70
0014105	Valve, Throttle	5	1.70
0014106	Valve, Throttle	5	1.70
0014108	Valve, Throttle	5	1.70
0014109	Valve, Throttle		
0014110	Valve, Throttle	5	1.70
0014111	Valve, Throttle	5	1.67
0014112	Valve, Throttle		
0014113	Valve, Throttle	5	1.70
0014114	Valve, Throttle		
0014115	Valve, Throttle		
0014116	Valve, Throttle		
0014118	Valve, Throttle	5	1.70
0014119	Valve, Throttle	5	1.70
0014120	Valve, Throttle	5	1.70
0014121	Valve, Throttle	5	1.70
0014122	Valve, Throttle		
0014126	Valve, Throttle		

0014128	Valve, Throttle		
0014129	Valve, Throttle		
0014130	Valve, Throttle	5	1.70
0014131	Valve, Throttle		
0014132	Valve, Throttle		
0014133	Valve, Throttle	5	1.70
0014134	Valve, Throttle	5	1.70
0014135	Valve, Throttle		
0014141	Valve, Throttle		
0014142	Valve, Throttle	5	1.70
0014151	Valve, Throttle	5	1.70
0014701	Valve, Throttle	5	1.70
0015001	Diaphragm, Pump	10	1.96
0015008	Diaphragm, Metering	10	3.51
0015009	Diaphragm, Metering	10	4.18
0015012	Diaphragm, Metering	10	4.04
0015014	Diaphragm, Metering	10	3.39
0015015	Diaphragm, Surge	10	1.59
0015016	Diaphragm, Surge	10	1.69
0015018	Diaphragm, Surge	10	1.87
0015021	Diaphragm, Pump	10	2.08
0015024	Diaphragm, Pump	10	2.48
0015038	Diaphragm, Pump	10	2.00
0015039	Diaphragm, Pump	10	2.68
0015040	Diaphragm, Pump	10	2.48
0015041	Diaphragm, Pump	10	3.53
0015044	Diaphragm, Pump	10	2.76
0015046	Diaphragm, Pump	10	2.48
0015047	Diaphragm, Pump	10	2.36
0015048	Diaphragm, Pump	10	2.48
0015049	Diaphragm, Pump	10	2.68
0015050	Diaphragm, Pump	10	2.36
0015051	Diaphragm, Pump	10	1.96
0015052	Diaphragm, Pump	10	2.03
0015057	Diaphragm, Pump	10	2.05
0015059	Diaphragm, Pump	10	2.05
0015060	Diaphragm, Pump	10	1.96
0015080	Diaphragm, Surge	10	2.18
0015081	Diaphragm, Pump	10	2.18
0015083	Diaphragm, Pump	10	2.76
0015084	Diaphragm, Surge	10	2.36
0015086	Diaphragm, Pump	10	2.76
0015091	Diaphragm, Pump	10	2.76

0015092	Diaphragm, Pump	10	2.73
0015103	Diaphragm, Pump	10	2.76
0015104	Diaphragm, Pump	10	2.76
0015110	Diaphragm, Pump	10	2.76
0016001	Gasket, Pump	10	0.59
0016004	Gasket, Pump	10	0.77
0016005	Gasket, Metering Chamber	10	0.56
0016008	Gasket, Metering Chamber	10	0.52
0016011	Gasket, Pump	10	0.49
0016012	Gasket, Metering Chamber	10	0.47
0016014	Gasket, Metering Chamber	10	0.49
0016015	Gasket, Pump	10	0.52
0016016	Gasket, Pump	10	0.90
0016018	Gasket, Metering Chamber	10	0.52
0016019	Gasket, Metering Chamber	10	0.62
0016021	Gasket, Metering Chamber	10	0.54
0016023	Gasket, Pump	10	0.49
0016024	Gasket, Metering Chamber	10	0.52
0016025	Gasket, Pump	10	0.54
0016027	Gasket, Metering Chamber	10	0.72
0016031	Gasket, Strainer	10	1.03
0016032	Gasket, Pump	10	0.62
0016033	Gasket, Pump	10	0.62
0016034	Gasket, Pump	10	0.55
0016035	Gasket, Metering Chamber	10	0.58
0016037	Gasket, Pump	10	1.12
0016039	Gasket, Pump	10	0.58
0016041	Gasket, Metering Chamber	10	1.12
0016042	Gasket, Metering Chamber	10	0.79
0016046	Gasket, Pump	10	0.53
0016047	Gasket, Pump	10	0.79
0016049	Gasket, Pump	10	0.61
0016050	Gasket, Pump	10	0.60
0016051	Gasket, Metering Chamber	10	0.61
0016073	Gasket, Pump	10	0.97
0016074	Gasket, Metering Chamber	10	1.82
0016075	Gasket, Metering Chamber	10	1.82
0016076	Gasket, Metering Chamber	10	1.82
0016077	Gasket, Metering Chamber	10	1.82
0016078	Gasket, Metering Chamber	10	1.82
0016079	Gasket, Metering Chamber	10	1.82
0016080	Gasket, Metering Chamber	10	1.82
0016083	Gasket, Pump	10	0.97

0016084	Gasket, Pump	10	0.97
0016085	Gasket, Metering Chamber	10	1.82
0016086	Gasket, Metering Chamber	10	0.97
0016087	Gasket, Pump	10	1.82
0016090	Gasket, Airhead	10	0.97
0016091	Gasket, Pump	10	1.82
0016092	Gasket, Pump	10	1.82
0016093	Gasket, Metering Chamber	10	1.82
0016094	Gasket, Airhead	10	1.82
0016095	Gasket, Metering Chamber		
0016096	Gasket, Pump	10	1.82
0016097	Gasket, Metering Chamber	10	1.82
0016098	Gasket, Metering Chamber	10	1.82
0016099	Gasket, Metering Chamber		
0016100	Gasket, Metering Chamber		
0016102	Gasket, Metering Chamber		
0016103	Gasket, Metering Chamber	10	1.82
0016104	Gasket, Airhead	10	1.82
0016105	Gasket, Metering Chamber		
0016701	Gasket, Metering Chamber	10	1.82
0017007	Cover, Pump	1	3.12
0017011	Cover, Pump	1	4.06
0017014	Cover, Pump	1	4.00
0017015	Cover, Pump	1	4.00
0017023	Cover, Pump	1	3.30
0017024	Cover, Pump		
0017025	Cover, Pump	1	4.00
0017026	Cover, Pump	1	4.02
0017027	Cover, Pump		
0017028	Cover, Pump		
0017029	Cover, Pump	1	6.12
0017032	Cover, Pump		
0017033	Cover, Pump	1	3.92
0017041	Cover, Pump	1	4.00
0017042	Cover, Pump	1	4.00
0017044	Cover, Pump	1	4.00
0017045	Cover, Pump	1	6.12
0017046	Cover, Pump	1	4.00
0017053	Cover, Pump	1	3.98
0017074	Cover, Pump	1	4.00
0017075	Cover, Pump		
0017077	Cover, Pump	1	4.00
0017079	Cover, Pump	1	4.00

0017081	Cover, Pump	1	4.00
0017088	Cover, Pump		
0017089	Cover, Pump	1	4.00
0017091	Cover, Pump	1	4.00
0017092	Cover, Pump	1	4.00
0017093	Cover, Pump		
0017094	Cover, Pump	1	4.00
0017095	Cover, Pump		
0017096	Cover, Pump		
0017098	Cover, Pump	1	4.00
0017101	Cover, Pump		
0017105	Cover, Pump		
0017111	Cover, Pump	1	4.00
0018002	Valve, Inlet Needle	10	2.72
0018004	Valve, Inlet Needle	10	2.99
0019002	Spring, Metering Lever	10	0.52
0019003	Spring, Metering Lever	10	0.65
0019005	Spring, Metering Lever	10	0.52
0019006	Spring, Metering Lever	10	0.59
0019007	Spring, Metering Lever	10	0.52
0019009	Spring, Metering Lever	10	0.59
0019011	Spring, Metering Lever	10	0.59
0019012	Spring, Metering Lever	10	0.59
0019013	Spring, Metering Lever	10	0.73
0019014	Spring, Metering Lever	10	0.59
0019015	Spring, Metering Lever	10	0.73
0019036	Spring, Metering Lever	10	0.73
0020002	Lever, Metering	10	0.58
0020003	Lever, Metering	10	0.84
0020005	Lever, Metering	10	0.70
0020006	Lever, Metering	10	0.70
0020008	Lever, Metering	10	0.75
0020009	Use 0020012		
0020010	Lever, Metering	10	0.80
0020011	Lever, Metering	10	0.95
0020012	Lever, Metering	10	0.65
0020033	Lever, Metering Chamber	10	0.84
0021001	Pin	10	0.39
0021002	Pin	10	0.39
0021007	Pin	10	0.61
0025004	Disk	10	0.54
0025005	Disk	10	0.54
0025006	Disk	10	0.54

0025007	Disk	10	0.54
0026001	Washer (Limiter)	10	0.38
0026003	Washer	10	0.38
0026005	Washer	10	0.38
0026006	Washer	10	0.38
0026011	Washer	10	1.43
0026013	Washer		
0026014	Washer	10	0.78
0026036	Washer	10	0.78
0026037	Washer	10	0.78
0028010	Discontinued		
0028012	Cover, Metering Chamber	1	2.25
0028015	Cover, Metering Chamber	1	2.32
0028018	Cover, Metering Chamber		
0028019	Cover, Metering Chamber		
0028020	Cover, Metering Chamber	1	2.26
0028021	Discontinued		
0028022	Cover, Metering Chamber	1	2.26
0028023	Cover, Metering Chamber	1	2.26
0028024	Discontinued		
0028026	Discontinued		
0028030	Discontinued		
0028033	Cover, Metering Chamber	1	2.26
0028036	Cover, Metering Chamber	1	2.26
0028038	Cover, Metering Chamber	1	2.26
0028039	Cover, Metering Chamber	1	2.26
0028040	Cover, Metering Chamber	1	2.26
0028042	Cover, Metering Chamber	1	2.26
0028043	Cover, Metering Chamber	1	2.26
0028044	Cover, Metering Chamber	1	2.26
0028045	Cover, Metering Chamber	1	2.26
0028047	Cover, Metering Chamber	1	2.26
0028048	Cover, Compensator	1	2.26
0028049	Cover, Metering Chamber	1	2.26
0028051	Cover, Metering Chamber		
0028057	Cover, Metering Chamber		
0028701	Cover, Metering Chamber	1	2.26
0029001	Spring, Adjust Screw	10	0.53
0029002	Spring, Adjust Screw	10	0.52
0029003	Spring, Adjust Screw	10	0.57
0029004	Spring, Adjust Screw	10	0.57
0029005	Spring, Adjust Screw	10	0.58
0029006	Spring, Adjust Screw	10	0.58

0029007	Spring, Adjust Screw	10	0.53
0029031	Spring, Adjust Screw	10	0.58
0029032	Spring, Adjust Screw	10	0.58
0029033	Spring, Adjust Screw	10	0.58
0029034	Spring, Adjust Screw	10	0.58
0029035	Discontinued		
0029036	Spring, Adjust Screw	10	0.58
0030002	Screw, Main Mixture	5	2.39
0030004	Screw, Main Mixture	5	2.39
0030005	Screw, Main Mixture	5	2.14
0030008	Discontinued		
0030017	Discontinued		
0030023	Screw, Main Mixture	5	2.17
0030024	Screw, Main Mixture	5	2.17
0030026	Discontinued		
0030030	Screw, Main Mixture	5	3.30
0030032	Screw, Main Mixture	5	3.08
0030037	Discontinued		
0030038	Screw, Main Mixture	5	5.49
0030039	Discontinued		
0030040	Discontinued		
0030041	Discontinued		
0030043	Screw, Main Mixture	5	3.08
0030044	Discontinued		
0030046	Screw, Main Mixture	5	2.17
0030048	Discontinued		
0030049	Screw, Main Mixture	5	2.17
0030052	Screw, Main Mixture	5	3.08
0030054	Discontinued		
0030055	Screw, Main Mixture	5	5.49
0030058	Discontinued		
0030059	Discontinued		
0030061	Screw, Main Mixture	5	2.17
0030063	Screw, Main Mixture	5	2.75
0030065	Screw, Main Mixture	5	2.66
0030072	Screw, Main Mixture	5	2.66
0030075	Discontinued		
0030076	Discontinued		
0030081	Discontinued		
0030086	Screw, Main Mixture	5	2.75
0030091	Discontinued		
0030092	Discontinued		
0030093	Discontinued		

0030096	Screw, Main Mixture	5	2.84
0030102	Discontinued		
0030105	Discontinued		
0030107	Screw, Main Mixture	5	2.66
0030108	Screw, Main Mixture	5	2.75
0030109	Screw, Main Mixture	5	2.75
0030111	Discontinued		
0030112	Screw, Main Mixture	5	2.75
0030113	Screw, Main Mixture	5	2.66
0030117	Screw, Main Mixture	5	2.66
0030139	Screw, Main Mixture	5	2.75
0030140	Screw, Main Mixture	5	2.75
0030144	Screw, Main Mixture	5	2.66
0030145	Screw, Main Mixture	5	2.75
0030148	Discontinued		
0030149	Screw, Main Mixture	5	2.75
0030150	Screw, Main Mixture	5	2.75
0030152	Screw, Main Mixture	5	2.75
0030153	Screw, Main Mixture	5	2.75
0030154	Screw, Main Mixture	5	3.08
0030155	Screw, Main Mixture	5	2.75
0030156	Screw, Main Mixture	5	3.08
0030157	Screw, Main Mixture	5	3.08
0030158	Screw, Main Mixture	5	2.66
0030159	Screw, Main Mixture	5	3.08
0030160	Screw, Main Mixture	5	3.08
0030161	Screw, Main Mixture	5	3.08
0030163	Screw, Main Mixture	5	3.08
0030164	Screw, Main Mixture	5	3.70
0030165	Screw, Main Mixture	5	3.70
0030166	Screw, Main Mixture	5	3.44
0030167	Screw, Main Mixture	5	3.08
0030168	Screw, Main Mixture	5	2.75
0030169	Screw, Main Mixture	5	2.96
0030170	Screw, Main Mixture	5	2.96
0030171	Screw, Main Mixture	5	2.96
0030172	Screw, Main Mixture	5	3.70
0030173	Screw, Main Mixture	5	3.44
0030174	Screw, Main Mixture	5	3.44
0030176	Screw, Main Mixture	5	3.59
0030177	Screw, Main Mixture	5	3.59
0030179	Screw, Main Mixture	5	3.59
0030180	Screw, Main Mixture		

0030181	Screw, Main Mixture	5	3.58
0030182	Screw, Main Mixture	5	3.58
0030183	Screw, Main Mixture	5	3.44
0030185	Screw, Main Mixture		
0030186	Screw, Main Mixture	5	3.59
0030187	Screw, Main Mixture	5	3.58
0030188	Screw, Main Mixture	5	3.58
0030189	Screw, Main Mixture	5	3.58
0030190	Screw, Main Mixture	5	3.34
0030191	Screw, Main Mixture	5	3.59
0030192	Screw, Main Mixture		
0030193	Screw, Main Mixture	5	3.58
0030194	Screw, Main Mixture	5	3.58
0030195	Screw, Main Mixture	5	3.58
0030196	Screw, Main Mixture		
0030197	Screw, Main Mixture	5	3.58
0030199	Screw, Main Mixture	5	3.58
0030200	Screw, Main Mixture		
0030201	Screw, Main Mixture	5	3.58
0030202	Screw, Main Mixture	5	3.58
0030203	Screw, Main Mixture	5	3.58
0030204	Screw, Main Mixture	5	3.58
0030205	Screw, Main Mixture	5	3.58
0030206	Screw, Main Mixture	5	3.58
0030207	Screw, Main Mixture	5	3.58
0030209	Screw, Main Mixture	5	3.58
0030210	Screw, Main Mixture	5	3.58
0030211	Screw, Main Mixture	5	3.58
0030212	Screw, Main Mixture	5	3.58
0030213	Screw, Main Mixture	5	3.58
0030214	Screw, Main Mixture	5	3.58
0030216	Screw, Main Mixture	5	3.58
0030217	Screw, Main Mixture	5	3.58
0030218	Screw, Main Mixture	5	3.58
0030219	Screw, Main Mixture	5	3.58
0030221	Screw, Main Mixture	5	3.58
0030222	Screw, Main Mixture	5	3.58
0030226	Screw, Main Mixture	5	3.58
0030227	Screw, Main Mixture		
0030228	Screw, Main Mixture	5	3.58
0030229	Screw, Main Mixture	5	3.58
0030230	Screw, Main Mixture		
0030231	Screw, Main Mixture		

0030232	Screw, Main Mixture		
0030233	Screw, Main Mixture		
0030234	Screw, Main Mixture	5	3.58
0030235	Screw, Main Mixture	5	3.58
0030236	Screw, Main Mixture	5	3.58
0030237	Screw, Main Mixture	5	3.58
0030238	Screw, Main Mixture	5	3.58
0030239	Screw, Main Mixture	5	3.58
0030240	Screw, Main Mixture	5	3.58
0030241	Screw, Main Mixture	5	3.58
0030242	Screw, Main Mixture		
0030243	Screw, Main Mixture	5	3.58
0030244	Screw, Main Mixture	5	3.58
0030245	Screw, Main Mixture		
0030246	Screw, Main Mixture		
0030247	Screw, Main Mixture		
0030248	Screw, Main Mixture	5	3.58
0030249	Screw, Main Mixture		
0030250	Screw, Main Mixture	5	3.58
0030251	Screw, Main Mixture	5	3.58
0030252	Screw, Main Mixture	5	3.58
0030253	Screw, Main Mixture		
0030254	Screw, Main Mixture	5	3.58
0030258	Screw, Main Mixture		
0030260	Screw, Main Mixture	5	3.58
0030262	Screw, Main Mixture		
0030264	Screw, Main Mixture		
0030265	Screw, Main Mixture	5	3.58
0030266	Screw, Main Mixture		
0030268	Screw, Main Mixture		
0030269	Screw, Main Mixture	5	3.58
0030270	Screw, Main Mixture	5	3.58
0030271	Screw, Main Mixture		
0030272	Screw, Main Mixture		
0030273	Screw, Main Mixture		
0031003	Screw, Idle Mixture	5	2.12
0031006	Screw, Idle Mixture	5	2.12
0031013	Screw, Idle Mixture	5	1.82
0031018	Screw, Idle Mixture	5	2.03
0031023	Screw, Idle Mixture	5	2.17
0031028	Screw, Idle Mixture	5	2.03
0031030	Screw, Idle Mixture	5	3.51
0031031	Screw, Idle Mixture	5	5.49

0031032	Screw, Idle Mixture	5	3.70
0031033	Screw, Idle Mixture	5	2.17
0031034	Screw, Idle Mixture	5	3.29
0031039	Screw, Idle Mixture	5	3.70
0031040	Screw, Idle Mixture	5	4.05
0031041	Screw, Idle Mixture	5	2.26
0031043	Screw, Idle Mixture	5	3.29
0031046	Screw, Idle Mixture	5	4.05
0031052	Screw, Idle Mixture	5	2.26
0031054	Screw, Idle Mixture	5	3.70
0031056	Screw, Idle Mixture	5	3.70
0031058	Screw, Idle Mixture	5	3.29
0031059	Screw, Idle Mixture	5	2.26
0031062	Screw, Idle Mixture	5	2.75
0031074	Screw, Idle Mixture	5	2.66
0031075	Screw, Idle Mixture	5	2.38
0031079	Screw, Idle Mixture	5	3.31
0031081	Screw, Idle Mixture	5	2.75
0031089	Screw, Idle Mixture	5	3.29
0031090	Screw, Idle Mixture	5	3.29
0031091	Screw, Idle Mixture	5	3.31
0031095	Screw, Idle Mixture	5	2.75
0031100	Screw, Idle Mixture	5	2.17
0031104	Screw, Idle Mixture	5	2.75
0031105	Screw, Idle Mixture	5	2.75
0031106	Screw, Idle Mixture	5	2.75
0031107	Screw, Idle Mixture	5	2.75
0031110	Screw, Idle Mixture	5	2.75
0031111	Screw, Idle Mixture	5	2.66
0031112	Screw, Idle Mixture	5	2.75
0031133	Screw, Idle Mixture	5	2.75
0031134	Screw, Idle Mixture	5	2.75
0031140	Screw, Idle Mixture	5	2.75
0031143	Screw, Idle Mixture	5	2.75
0031144	Screw, Idle Mixture	5	2.75
0031146	Screw, Idle Mixture	5	2.75
0031151	Screw, Idle Mixture	5	2.75
0031152	Screw, Idle Mixture	5	3.29
0031154	Screw, Idle Mixture	5	3.58
0031156	Screw, Idle Mixture	5	3.29
0031157	Screw, Idle Mixture	5	3.58
0031158	Screw, Idle Mixture	5	3.58
0031159	Screw, Idle Mixture	5	3.51

0031160	Screw, Idle Mixture	5	3.58
0031162	Screw, Idle Mixture	5	3.51
0031163	Screw, Idle Mixture	5	2.75
0031165	Screw, Idle Mixture	5	3.44
0031167	Screw, Idle Mixture	5	3.44
0031168	Screw, Idle Mixture	5	3.51
0031169	Screw, Idle Mixture	5	3.51
0031170	Screw, Idle Mixture	5	3.51
0031171	Screw, Idle Mixture	5	3.51
0031172	Screw, Idle Mixture	5	3.44
0031173	Screw, Idle Mixture	5	3.58
0031174	Screw, Idle Mixture	5	3.44
0031175	Screw, Idle Mixture	5	3.44
0031178	Screw, Idle Mixture	5	3.58
0031179	Screw, Idle Mixture	5	3.58
0031180	Screw, Idle Mixture	5	3.58
0031183	Screw, Idle Mixture	5	3.58
0031184	Screw, Idle Mixture	5	3.58
0031185	Screw, Idle Mixture	5	3.58
0031188	Screw, Idle Mixture	5	3.58
0031191	Screw, Idle Mixture		
0031192	Screw, Idle Mixture	5	3.58
0031193	Screw, Idle Mixture	5	3.58
0031195	Screw, Idle Mixture	5	3.58
0031196	Screw, Idle Mixture	5	3.58
0031197	Screw, Idle Mixture	5	3.58
0031198	Screw, Idle Mixture	5	3.58
0031199	Screw, Idle Mixture	5	3.58
0031200	Screw, Idle Mixture	5	3.59
0031204	Screw, Idle Mixture	5	3.58
0031206	Screw, Idle Mixture	5	3.58
0031207	Screw, Idle Mixture	5	3.58
0031209	Screw, Idle Mixture	5	3.58
0031210	Screw, Idle Mixture	5	3.58
0031212	Screw, Idle Mixture	5	3.58
0031213	Screw, Idle Mixture	5	3.58
0031214	Screw, Idle Mixture	5	3.58
0031215	Screw, Idle Mixture	5	3.58
0031216	Screw, Idle Mixture	5	3.58
0031219	Screw, Idle Mixture	5	3.58
0031220	Screw, Idle Mixture	5	3.58
0031221	Screw, Idle Mixture	5	3.58
0031222	Screw, Idle Mixture		

0031223	Screw, Idle Mixture	5	3.58
0031224	Screw, Idle Mixture	5	3.58
0031225	Screw, Idle Mixture	5	3.58
0031228	Screw, Idle Mixture	5	3.58
0031229	Screw, Idle Mixture	5	3.58
0031230	Screw, Idle Mixture	5	3.58
0031231	Screw, Idle Mixture		
0031233	Screw, Idle Mixture	5	3.58
0031236	Screw, Idle Mixture	5	3.58
0031237	Screw, Idle Mixture	5	3.58
0031239	Screw, Idle Mixture	5	3.58
0031240	Screw, Idle Mixture	5	3.58
0031241	Screw, Idle Mixture	5	3.58
0031242	Screw, Idle Mixture		
0031243	Screw, Idle Mixture	5	3.58
0031244	Screw, Idle Mixture	5	3.58
0031248	Screw, Idle Mixture	5	3.58
0031251	Screw, Idle Mixture	5	3.58
0031255	Screw, Idle Mixture	5	3.58
0031256	Screw, Idle Mixture		
0031257	Screw, Idle Mixture	5	3.58
0031258	Screw, Idle Mixture	5	3.58
0031259	Screw, Idle Mixture	5	3.58
0031263	Screw, Idle Mixture	5	3.58
0031264	Screw, Idle Mixture	5	3.58
0031265	Screw, Idle Mixture		
0031266	Screw, Idle Mixture	5	3.58
0035007	Screw, Throttle Adjust	10	0.72
0035009	Screw, Throttle Adjust	10	2.11
0035011	Screw, Throttle Adjust	10	2.20
0035014	Screw, Throttle Adjust	10	2.20
0035016	Screw, Throttle Adjust	10	2.11
0035017	Screw, Throttle Adjust	10	2.59
0035020	Screw, Throttle Adjust	10	2.11
0035022	Screw, Throttle Adjust	10	2.11
0035023	Screw, Throttle Adjust	10	2.11
0035024	Screw, Throttle Adjust	10	2.11
0035026	Screw, Throttle Adjust	10	2.75
0035029	Screw, Throttle Adjust	10	2.11
0035030	Screw, Throttle Adjust	10	2.40
0035031	Screw, Throttle Adjust	10	0.72
0035033	Screw, Throttle Adjust	10	2.11
0035035	Screw, Throttle Adjust	10	2.40

0035036	Screw, Throttle Adjust	10	2.75
0035037	Screw, Throttle Adjust	10	2.20
0035058	Screw, Throttle Adjust	10	2.40
0035060	Screw, Throttle Adjust	10	2.16
0035062	Screw, Throttle Adjust	10	2.75
0035064	Screw, Air Adjust	10	3.34
0035065	Screw, Throttle Adjust	10	3.34
0035066	Screw, Air Adjust	10	3.34
0035067	Screw, Throttle Adjust	10	3.34
0035069	Screw, Air Adjust	10	3.34
0035070	Screw, Throttle Adjust	10	3.34
0035072	Screw, Throttle Adjust	10	3.34
0035073	Screw, Throttle Adjust	10	3.34
0035075	Screw, Throttle Adjust	10	3.34
0035079	Screw, Throttle Adjust	10	3.34
0035080	Screw, Throttle Adjust	10	3.34
0035081	Screw, Throttle Adjust	10	3.34
0035082	Screw, Air Adjust	10	3.34
0036001	Piece, Friction	10	0.87
0036002	Use 0036001		
0037002	Retainer, Pump Diaphragm	10	1.58
0037003	Retainer, Pump Diaphragm	10	1.17
0037004	Retainer, Pump Diaphragm	10	1.40
0038001	Spring, Choke	10	0.55
0038002	Spring, Choke	10	0.68
0041003	Shaft, Choke	1	2.76
0041009	Shaft, Choke	1	3.67
0041015	Shaft, Choke	1	4.56
0041024	Shaft, Choke	1	3.67
0041028	Shaft, Choke	1	3.67
0041035	Shaft, Choke	1	3.67
0041039	Shaft, Choke	1	4.76
0041042	Shaft, Choke	1	4.76
0041043	Use 0041081		
0041047	Shaft, Choke	1	4.20
0041051	Shaft, Choke	1	4.76
0041076	Shaft, Choke	1	4.76
0041077	Shaft, Choke	1	4.76
0041078	Shaft, Choke	1	4.20
0041081	Shaft, Choke	1	4.20
0041088	Shaft, Choke	1	4.57
0041095	Shaft, Choke	1	4.20
0041096	Shaft, Choke	1	4.57

0041097	Shaft, Choke	1	4.57
0041098	Shaft, Choke	1	4.57
0041102	Shaft, Choke	1	4.57
0041107	Shaft, Choke	1	4.57
0041113	Shaft, Choke	1	4.57
0041114	Shaft, Yellow Choke	1	4.57
0041115	Shaft, Choke	1	4.57
0041120	Shaft, Choke	1	4.57
0041128	Shaft, Choke	1	4.57
0041134	Shaft, Choke	1	4.57
0041137	Shaft, Choke	1	4.57
0041140	Shaft, Choke	1	4.57
0041141	Shaft, Choke	1	4.57
0041148	Shaft, Choke	1	4.57
0041156	Shaft, Choke	1	4.57
0041162	Shaft, Choke	1	4.57
0041163	Shaft, Choke	1	4.57
0041165	Shaft, Choke	1	4.57
0042022	Lever, Choke	5	0.77
0042040	Lever, Choke	5	0.77
0042055	Lever, Choke	5	0.77
0042078	Lever, Choke	5	0.77
0042081	Lever, Choke	5	0.77
0042083	Lever, Choke	5	1.31
0042084	Lever, Choke Actuator	5	1.38
0042087	Lever, Choke	5	1.31
0042088	Lever, Choke	5	1.31
0042090	Lever, Choke Actuator	5	1.19
0042091	Lever, Choke		
0042092	Lever, Choke	5	1.31
0042094	Lever, Choke	5	1.31
0042097	Lever, Choke	5	1.38
0042098	Lever, Choke	5	1.31
0042100	Lever, Choke	5	1.38
0042101	Lever, Choke		
0042103	Lever, Choke	5	1.38
0042105	Lever, Choke Actuator	5	1.38
0042111	Lever, Fast Idle	5	1.38
0042113	Lever, Choke	5	1.38
0042116	Lever, Choke	5	1.38
0042117	Lever, Choke		
0042118	Lever, Choke	5	1.38
0042120	Lever, Choke	5	1.38

0042124	Lever, Choke	5	1.38
0042127	Lever, Choke	5	1.38
0042128	Lever, Choke	5	1.38
0042130	Lever, Choke	5	1.38
0042131	Lever, Choke	5	1.38
0042132	Lever, Choke Actuator	5	1.38
0042134	Lever, Choke	5	1.31
0042135	Lever, Choke		
0042137	Lever, Choke	5	1.38
0042140	Lever, Choke	5	1.38
0042144	Lever, Choke	5	1.38
0042146	Lever, Choke	5	1.38
0042148	Lever, Choke		
0042149	Lever, Choke Actuator	5	1.38
0042152	Lever, Fast Idle	5	1.38
0042154	Lever, Choke	5	1.38
0042157	Lever, Choke	5	1.38
0042159	Lever, Choke	5	1.38
0042160	Lever, Choke	5	1.38
0042162	Lever, Choke	5	1.38
0042164	Lever, Choke	5	1.38
0042169	Lever, Choke		
0042171	Lever, Choke	5	1.38
0042172	Lever, Choke	5	1.38
0042173	Lever, Choke	5	1.38
0042175	Lever, Choke Actuator	5	1.38
0042177	Lever, Choke		
0042178	Lever, Choke Actuator	5	1.38
0042179	Lever, Choke		
0042182	Lever, Choke	5	1.38
0042183	Lever, Choke Fast Idle	5	1.38
0042187	Lever, Choke Actuator	5	1.38
0042188	Lever, Choke Actuator	5	1.38
0042193	Lever, Choke	5	1.38
0042196	Lever, Choke Actuator	5	1.38
0042200	Lever, Choke	5	1.39
0042702	Lever, Choke	5	1.38
0043001	Valve, Choke	5	0.75
0043007	Valve, Choke	5	0.65
0043008	Valve, Choke	5	0.62
0043009	Valve, Choke	5	1.71
0043010	Valve, Choke	5	0.69
0043011	Valve, Choke	5	0.83

0043012	Valve, Choke	5	1.38
0043014	Valve, Choke	5	1.34
0043015	Valve, Choke	5	1.42
0043016	Valve, Choke	5	1.40
0043017	Valve, Choke	5	1.40
0043018	Valve, Choke	5	1.13
0043019	Valve, Choke	5	0.77
0043021	Valve, Choke	5	1.42
0043022	Valve, Choke	5	1.42
0043025	Valve, Choke	5	1.42
0043026	Valve, Choke	5	1.42
0043027	Valve, Choke	5	0.94
0043028	Valve, Choke	5	0.77
0043049	Valve, Choke		
0043050	Valve, Choke		
0043051	Valve, Choke	5	1.42
0043053	Valve, Choke	5	1.42
0043054	Valve, Choke	5	1.42
0043055	Valve, Choke	5	1.42
0043056	Valve, Choke	5	1.42
0043057	Valve, Choke	5	1.42
0043058	Valve, Choke	5	1.13
0043059	Valve, Choke	5	1.42
0043060	Valve, Choke		
0043061	Valve, Choke	5	1.42
0043063	Valve, Choke	5	1.42
0043064	Valve, Choke	5	1.42
0043065	Valve, Choke	5	1.42
0043067	Valve, Choke	5	1.42
0043069	Valve, Choke	5	1.42
0043071	Valve, Choke	5	1.42
0043074	Valve, Choke	5	1.42
0043075	Valve, Choke	5	1.42
0043078	Valve, Choke	5	1.42
0043079	Valve, Choke	5	1.42
0045002	Post	5	2.12
0045003	Post	5	1.81
0045004	Post	5	3.24
0045010	Post	5	1.81
0045011	Post	5	2.63
0045012	Post	5	2.27
0045036	Post		
0045037	Post	5	2.55

0045038	Post	5	3.24
0045040	Post	5	2.55
0045043	Post	5	3.17
0045044	Post	5	3.17
0045047	Post		
0045050	Post	5	3.17
0045054	Post	5	3.17
0049001	Body, Pump	1	2.69
0049002	Body, Pump	1	6.12
0049003	Body, Pump	1	6.12
0051004	Boot	5	1.43
0051005	Boot	5	1.43
0051027	Boot	5	1.43
0052001	Collar	5	0.60
0052004	Collar	5	0.60
0052005	Collar	5	0.60
0052007	Collar	5	0.60
0052008	Collar	5	0.60
0052009	Collar	5	0.60
0052010	Collar	5	0.60
0052011	Collar	5	0.60
0052013	Collar	5	0.60
0052014	Collar	5	0.60
0052015	Collar	5	0.60
0052017	Collar	5	0.60
0052019	Collar	5	0.60
0052020	Collar	5	0.60
0052021	Collar	5	0.60
0052702	Collar	5	0.60
0053001	Plunger	10	1.15
0053003	Plunger	10	1.15
0053004	Plunger	10	1.15
0053005	Plunger	10	1.35
0053008	Plunger	10	1.35
0053009	Plunger	10	1.35
0053030	Plunger	10	1.35
0053033	Plunger	10	1.35
0053034	Plunger	10	1.35
0053039	Plunger	10	1.35
0053041	Plunger	10	1.35
0053042	Plunger	10	1.35
0053044	Plunger	10	1.35
0053046	Plunger	10	1.35

0053047	Plunger	10	1.35
0053049	Plunger	10	1.35
0053052	Plunger	10	1.35
0053053	Plunger	10	1.35
0053061	Plunger	10	1.35
0053062	Plunger	10	1.35
0053063	Plunger	10	1.35
0053065	Plunger	10	1.35
0053067	Plunger	10	1.35
0054001	Spring	10	0.39
0054002	Spring	10	0.39
0054004	Discontinued		
0054010	Spring, Choke Return	10	0.39
0054012	Spring, Conical	10	1.29
0054025	Spring, Plunger Return	10	0.58
0054051	Spring	10	1.09
0054055	Spring, Plunger Return	10	1.29
0054056	Spring, Pump	10	1.29
0054057	Spring, Plunger Return	10	1.29
0054059	Spring	10	1.29
0054065	Spring, Plunger Return	10	1.29
0054066	Spring, Plunger Return	10	1.29
0054068	Spring, Retainer	10	1.29
0057001	Use 0057004		
0057003	Syringe	10	1.77
0057004	Syringe	10	1.77
0057025	Syringe, Red	10	1.94
0058001	Screw	10	0.89
0058022	Screw	10	0.89
0061001	Limiter, Mixture	10	0.53
0061002	Limiter, Mixture	10	0.53
0061003	Limiter (H)	10	0.77
0061004	Discontinued		
0061005	Limiter (H)	10	1.01
0061006	Limiter (L)	10	1.01
0061007	Limiter (H)	10	1.01
0061009	Limiter (H)	10	0.95
0061010	Limiter (L)	10	1.01
0061015	Limiter (H)	10	1.01
0061016	Limiter (L)	10	1.01
0061017	Limiter (L)	10	1.01
0061025	Limiter (H)	10	1.01
0061026	Limiter (L)	10	1.01

0061027	Limiter (H)	10	1.01
0061028	Limiter (L)	10	1.01
0061029	Limiter (L)		
0061030	Limiter (H)		
0061051	Limiter (H)	10	1.11
0061053	Limiter Tamper Resist		
0061054	Limiter Tamper Resist		
0061055	Limiter Tamper Resist		
0061056	Limiter Tamper Resist	10	1.01
0061057	Limiter Tamper Resist		
0061058	Limiter Tamper Resist	10	1.01
0061059	Limiter Tamper Resist	10	1.01
0061060	Limiter Tamper Resist	10	1.01
0061062	Limiter Tamper Resist	10	1.01
0061063	Limiter Tamper Resist	10	1.01
0061064	Limiter Tamper Resist	10	1.01
0061067	Limiter Tamper Resist	10	1.01
0061074	Limiter Tamper Resist		
0063026	Rod Linkage	1	0.52
0063027	Rod Linkage	1	0.52
0063028	Rod Linkage	1	0.52
0063030	Rod Linkage	1	0.52
0063701	Rod Linkage Airhead	1	0.52
0070039	Jet, Remote (0.34)	1	1.63
0070040	Jet, Remote (0.35)	1	1.70
0070042	Jet, Remote (0.37)	1	1.70
0070066	Jet, Remote (0.26)	1	1.70
0070070	Jet, Remote (0.30)	1	1.60
0070072	Jet, Remote (0.32)	1	1.70
0070073	Jet, Remote (0.33)	1	1.60
0070074	Jet, Remote (0.36)	1	1.60
0070076	Jet, Remote (0.39)	1	1.70
0070077	Jet, Remote (0.40)	1	1.70
0070078	Jet, Remote (0.41)	1	1.70
0070079	Jet, Remote (0.42)	1	1.70
0070080	Jet, Remote (0.43)	1	1.70
0070081	Jet, Remote (0.44)	1	1.70
0070082	Jet, Remote (0.45)	1	1.60
0070083	Jet, Remote (0.46)	1	1.60
0070084	Jet, Remote (0.47)	1	1.60
0070085	Use 0070089		
0070086	Jet, Remote	1	1.60
0070087	Jet, Remote (0.50)	1	1.60

0070089	Jet, Remote (0.52)	1	1.70
0070112	Jet, Remote	1	1.70
0070114	Jet, Remote	1	1.70
0070116	Jet, Remote	1	1.70
0070131	Jet, Remote	1	1.70
0070132	Jet, Remote	1	1.70
0070133	Jet, Remote	1	1.70
0077001	Nut, Cable	1	2.32
0080002	Screw, Wire Adjust	1	2.32
0080003	Screw, Wire Adjust	1	2.32
0080004	Screw, Wire Adjust	1	2.32
0080005	Screw, Wire Adjust	1	2.32
0080006	Screw, Wire Adjust	1	2.32
0080008	Screw, Wire Adjust	1	2.32
0080009	Screw, Wire Adjust	1	2.32
0080010	Screw, Wire Adjust	1	2.32
0080012	Screw, Wire Adjust	1	2.32
0082001	Roller Guide	1	1.06
0082002	Roller Guide	1	1.06
0082003	Roller Guide	1	1.06
0088003	Body, Air Cleaner	1	18.80
0088018	Body, Airhead	1	3.30
0089002	Rod Starter	1	3.15
0089004	Rod Starter	1	3.15
0089009	Rod Starter	1	3.15
9016028	Intake Gasket	10	0.75
9016051	Intake Gasket	10	0.97
9016060	Intake Gasket	10	0.76
9016068	Intake Gasket	10	0.76
9016121	Intake Gasket	10	0.82
9016122	Intake Gasket	10	0.77
9016124	Intake Gasket	10	0.79
9016141	Intake Gasket	10	0.91
9016147	Intake Gasket	10	0.91
9016176	Intake Gasket	10	0.91
9016320	Intake Gasket	10	0.91
9016355	Intake Gasket	10	1.12
9016450	Intake Gasket	10	0.91
9016544	Intake Gasket	10	1.14
9016647	Intake Gasket	10	1.08
9016675	Intake Gasket	10	1.11
9016756	Intake Gasket	10	1.05
9016910	Intake Gasket	10	0.91

9016987	Intake Gasket	10	1.07
14803006	Screw	10	0.38
14902509	Screw	10	0.38
14903006	Screw	10	0.38
14903008	Screw, Throttle Adjust	10	0.38
14903010	Screw, Airhead	10	0.38
14904010	Screw, Pump Cover	10	0.38
15603004	Screw	10	0.52
15702545	Screw, Throttle Valve	10	0.62
16103005	Screw	10	0.57
16103008	Screw	10	0.76
16103012	Screw	10	0.76
16103014	Screw	10	0.76
16104010	Screw	10	0.76
16104022	Screw	10	0.76
16104024	Screw	10	0.76
16105006	Screw	10	0.76
16303008	Screw	10	0.38
16303520	Screw	10	0.67
16304008	Screw	10	0.52
16304018	Screw	10	0.76
16403006	Screw	10	0.68
16503006	Screw	10	0.82
17002504	Screw	10	0.40
17004010	Screw	10	0.40
17014010	Screw	10	0.40
17103004	Screw	10	0.38
17103007	Screw	10	0.38
17103008	Screw	10	0.38
17103009	Screw, Metering Cover	10	0.38
17103011	Screw	10	0.62
17103012	Use 17203012		
17103015	Screw	10	0.62
17103017	Screw	10	0.46
17104009	Screw	10	0.40
17104010	Screw	10	0.62
17104012	Screw	10	0.40
17104015	Screw	10	0.58
17104023	Screw, Pump Cover	10	0.62
17124015	Screw, Pump Cover		
17203006	Screw	10	0.40
17203007	Screw, Metering Cover	10	0.58
17203009	Screw	10	0.40

17203012	Screw (Retainer)	10	0.38
17203015	Screw	10	0.40
17203021	Screw	10	0.40
17404012	Screw, Pump Cover	10	0.77
17502604	Screw	10	0.77
19290030	Ball, Steel	10	0.53
19290040	Ball, Steel	10	0.53
19500019	E-Ring	10	0.39
19500020	E-Ring	10	0.38
19500024	E-Ring	10	0.38
19500025	E-Ring	10	0.38
19500030	E-Ring	10	0.38
19500035	E-Ring	10	0.39
19500040	E-Ring	10	0.39
19510040	E-Ring	10	0.38
19520120	C-Ring	10	1.97
149025055	Screw	10	0.38
149030055	Screw, Metering Pin	10	0.38
156030045	Screw	10	0.53
156030055	Screw	10	0.54
157025045	Screw	10	0.62
161025003	Screw	10	0.76
161029055	Screw	10	0.76
170025045	Screw	10	0.40
172030135	Screw	10	0.58
195502010	O-Ring	10	2.25
195502308	O-Ring	10	2.25
195502309	O-Ring	10	2.25
195503010	O-Ring	10	2.25
195503510	O-Ring, Plunger	10	2.25
195503515	O-Ring	10	2.25
195505015	O-Ring	10	2.25
195505178	Quad Ring	10	2.25
195507015	O-Ring	10	2.25
195519005	O-Ring	10	2.25
195602308	O-Ring	10	2.25
195702308	O-Ring	10	2.25
195703010	O-Ring	10	2.25
195703510	O-Ring	10	2.25
195704010	O-Ring		
0015030V	Diaphragm, Pump	10	2.73
0015031V	Diaphragm, Pump	10	2.76
0015032V	Diaphragm, Pump	10	2.68

0015033V	Diaphragm, Pump	10	2.68
A007009E	Nozzle Ass'y, Check Valve	5	2.17
A007010	Nozzle Ass'y, Check Valve	5	1.90
A007011	Nozzle Ass'y, Check Valve	5	2.34
A007013	Nozzle Ass'y, Check Valve	5	1.92
A007019	Nozzle Ass'y, Check Valve	5	3.35
A007022	Nozzle Ass'y, Check Valve	5	2.72
A007023	Nozzle Ass'y, Check Valve	5	2.34
A007025	Nozzle Ass'y, Check Valve	5	3.35
A007026	Nozzle Ass'y, Check Valve	5	2.72
A007027	Nozzle Ass'y, Check Valve	5	2.34
A007028	Nozzle Ass'y, Check Valve	5	2.34
A007029	Nozzle Ass'y, Check Valve	5	2.72
A007030	Nozzle Ass'y, Check Valve	5	2.34
A007032	Nozzle Ass'y, Check Valve	5	2.72
A007033	Nozzle Ass'y, Check Valve	5	2.72
A007036	Nozzle Ass'y, Check Valve	5	2.55
A007037	Nozzle Ass'y, Check Valve	5	2.44
A007039	Nozzle Ass'y, Check Valve	5	2.44
A007042	Nozzle Ass'y, Check Valve	5	2.44
A007045	Nozzle Ass'y, Check Valve	5	2.72
A007048	Nozzle Ass'y, Check Valve	5	2.72
A007051	Nozzle Ass'y, Check Valve	5	5.22
A007053	Nozzle Ass'y, Check Valve	5	5.43
A007055	Nozzle Ass'y, Check Valve	5	5.22
A007056	Nozzle Ass'y, Check Valve	5	2.54
A007057	Nozzle Ass'y, Check Valve	5	2.54
A007059	Nozzle Ass'y, Check Valve	5	2.44
A007060	Nozzle Ass'y, Check Valve	5	2.54
A007062	Nozzle Ass'y, Check Valve	5	2.72
A007063	Nozzle Ass'y, Check Valve	5	2.44
A007064	Nozzle Ass'y, Check Valve	5	3.51
A007066	Nozzle Ass'y, Check Valve	5	2.60
A007067	Nozzle Ass'y, Check Valve	5	2.60
A007068	Nozzle Ass'y, Check Valve	5	2.60
A007075	Nozzle Ass'y, Check Valve	5	2.60
A007077	Nozzle Ass'y, Check Valve	5	2.72
A007079	Nozzle Ass'y, Check Valve	5	2.60
A007080	Nozzle Ass'y, Check Valve	5	2.72
A007082	Nozzle Ass'y, Check Valve	5	2.72
A007103	Nozzle Ass'y, Check Valve	5	2.72
A007107	Nozzle Ass'y, Check Valve	5	2.72
A007109	Nozzle Ass'y, Check Valve	5	2.72

A007110	Nozzle Ass'y, Check Valve	5	3.63
A007112	Nozzle Ass'y, Check Valve	5	2.72
A007114	Nozzle Ass'y, Check Valve	5	2.60
A007115	Nozzle Ass'y, Check Valve	5	2.72
A007117	Nozzle Ass'y, Check Valve	5	3.51
A007119	Nozzle Ass'y, Check Valve	5	3.51
A007120	Nozzle Ass'y, Check Valve	5	3.51
A007121	Nozzle Ass'y, Check Valve	5	3.51
A007122	Nozzle Ass'y, Check Valve	5	3.81
A007123	Nozzle Ass'y, Check Valve	5	2.72
A007126	Nozzle Ass'y, Check Valve	5	2.72
A007129	Nozzle Ass'y, Check Valve	5	2.72
A007132	Nozzle Ass'y, Check Valve	5	3.81
A007133	Nozzle Ass'y, Check Valve	5	3.81
A007135	Nozzle Ass'y, Check Valve	5	3.81
A007136	Nozzle Ass'y, Check Valve	5	3.81
A007137	Nozzle Ass'y, Check Valve	5	3.39
A007138	Nozzle Ass'y, Check Valve	5	3.39
A007139	Nozzle Ass'y, Check Valve	5	3.81
A007142	Nozzle Ass'y, Check Valve	5	3.81
A007143	Nozzle Ass'y, Check Valve	5	3.67
A007144	Nozzle Ass'y, Check Valve	5	3.51
A007145	Nozzle Ass'y, Check Valve	5	2.60
A007146	Nozzle Ass'y, Check Valve	5	2.72
A007147	Nozzle Ass'y, Check Valve	5	2.60
A007148	Nozzle Ass'y, Check Valve	5	2.60
A007149	Nozzle Ass'y, Check Valve	5	2.60
A007150	Nozzle Ass'y, Check Valve	5	2.72
A007151	Nozzle Ass'y, Check Valve	5	2.60
A007152	Nozzle Ass'y, Check Valve	5	3.51
A007153	Nozzle Ass'y, Check Valve	5	3.81
A007154	Nozzle Ass'y, Check Valve	5	3.51
A007155	Nozzle Ass'y, Check Valve	5	3.51
A007156	Nozzle Ass'y, Check Valve	5	3.81
A007157	Nozzle Ass'y, Check Valve	5	3.67
A007158	Nozzle Ass'y, Check Valve	5	3.81
A007162	Nozzle Ass'y, Check Valve	5	3.81
A007163	Nozzle Ass'y, Check Valve	5	2.72
A007164	Nozzle Ass'y, Check Valve	5	3.81
A007165	Nozzle Ass'y, Check Valve	5	3.81
A007166	Nozzle Ass'y, Check Valve	5	3.39
A007167	Nozzle Ass'y, Check Valve	5	3.81
A007168	Nozzle Ass'y, Check Valve	5	3.81

A007169	Nozzle Ass'y, Check Valve	5	3.81
A007170	Nozzle Ass'y, Check Valve	5	3.81
A007175	Nozzle Ass'y, Check Valve	5	3.81
A007176	Nozzle Ass'y, Check Valve	5	3.81
A007179	Nozzle Ass'y, Check Valve	5	3.81
A007180	Nozzle Ass'y, Check Valve	5	3.81
A007181	Use A007193		
A007183	Nozzle Ass'y, Check Valve	5	3.81
A007185	Nozzle Ass'y, Check Valve	5	3.81
A007186	Nozzle Ass'y, Check Valve	5	3.81
A007187	Nozzle Ass'y, Check Valve	5	3.81
A007188	Nozzle Ass'y, Check Valve	5	3.81
A007189	Nozzle Ass'y, Check Valve	5	3.81
A007190	Nozzle Ass'y, Check Valve	5	3.81
A007191	Nozzle Ass'y, Check Valve	5	3.81
A007193	Nozzle Ass'y, Check Valve	5	3.81
A007194	Nozzle Ass'y, Check Valve	5	3.81
A007196	Nozzle Ass'y, Check Valve	5	3.81
A007197	Nozzle Ass'y, Check Valve	5	3.81
A007198	Nozzle Ass'y, Check Valve	5	3.81
A007199	Nozzle Ass'y, Check Valve	5	3.81
A007200	Nozzle Ass'y, Check Valve	5	3.81
A007201	Nozzle Ass'y, Check Valve	5	3.81
A007202	Nozzle Ass'y, Check Valve	5	3.81
A007203	Nozzle Ass'y, Check Valve	5	3.81
A007204	Nozzle Ass'y, Check Valve	5	3.81
A007206	Nozzle Ass'y, Check Valve	5	3.81
A007207	Nozzle Ass'y, Check Valve	5	3.81
A007208	Nozzle Ass'y, Check Valve	5	3.81
A007210	Nozzle Ass'y, Check Valve	5	3.81
A007211	Nozzle Ass'y, Check Valve	5	3.81
A007212	Nozzle Ass'y, Check Valve	5	3.81
A007213	Nozzle Ass'y, Check Valve	5	3.81
A007214	Nozzle Ass'y, Check Valve	5	3.81
A007218	Nozzle Ass'y, Check Valve	5	3.81
A007219	Nozzle Ass'y, Check Valve	5	3.81
A007220	Nozzle Ass'y, Check Valve	5	3.81
A007222	Nozzle Ass'y, Check Valve	5	3.81
A007223	Nozzle Ass'y, Check Valve	5	3.81
A007227	Nozzle Ass'y, Check Valve	5	3.81
A007228	Nozzle Ass'y, Check Valve	5	3.81
A007229	Nozzle Ass'y, Check Valve	5	3.81
A007230	Nozzle Ass'y, Check Valve	5	3.81

A007231	Nozzle Ass'y, Check Valve	5	3.81
A007232	Nozzle Ass'y, Check Valve	5	3.81
A007233	Nozzle Ass'y, Check Valve	5	3.81
A007234	Nozzle Ass'y, Check Valve	5	3.81
A007235	Nozzle Ass'y, Check Valve	5	3.81
A007237	Nozzle Ass'y, Check Valve	5	3.81
A007238	Nozzle Ass'y, Check Valve	5	3.81
A007239	Nozzle Ass'y, Check Valve	5	3.81
A007240	Nozzle Ass'y, Check Valve	5	3.81
A007243	Nozzle Ass'y, Check Valve	5	3.81
A007245	Nozzle Ass'y, Check Valve	5	3.81
A007251	Nozzle Ass'y, Check Valve	5	3.81
A007252	Nozzle Ass'y, Check Valve	5	3.81
A007254	Nozzle Ass'y, Check Valve	5	3.81
A007255	Nozzle Ass'y, Check Valve	5	3.81
A007262	Nozzle Ass'y, Check Valve	5	3.81
A007268	Nozzle Ass'y, Check Valve	5	3.81
A007269	Nozzle Ass'y, Check Valve	5	3.81
A007702	Nozzle Ass'y, Check Valve	5	3.81
A007703	Nozzle Ass'y, Check Valve	5	3.81
A011003	Shaft Ass'y, Throttle	1	2.72
A011007	Shaft Ass'y, Throttle	1	3.06
A011017	Shaft Ass'y, Throttle	1	3.28
A011019	Shaft Ass'y, Throttle	1	2.96
A011022	Shaft Ass'y, Throttle	1	3.76
A011030	Shaft Ass'y, Throttle	1	3.24
A011036	Shaft Ass'y, Throttle	1	4.97
A011037	Shaft Ass'y, Throttle	1	5.24
A011042	Shaft Ass'y, Throttle	1	3.48
A011043	Shaft Ass'y, Throttle	1	3.31
A011045	Shaft Ass'y, Throttle	1	6.13
A011048	Shaft Ass'y, Throttle	1	3.29
A011050	Shaft Ass'y, Throttle	1	3.42
A011051	Shaft Ass'y, Throttle	1	3.05
A011052	Shaft Ass'y, Throttle	1	3.15
A011055	Shaft Ass'y, Throttle	1	3.29
A011057	Shaft Ass'y, Throttle	1	3.86
A011058	Shaft Ass'y, Throttle	1	6.13
A011059	Shaft Ass'y, Throttle	1	3.86
A011060	Shaft Ass'y, Throttle	1	3.34
A011062	Shaft Ass'y, Throttle	1	3.47
A011063	Shaft Ass'y, Throttle	1	3.47
A011067	Shaft Ass'y, Throttle	1	3.34

A011072	Shaft Ass'y, Throttle	1	3.71
A011073	Shaft Ass'y, Throttle	1	3.71
A011074	Discontinued		
A011075	Shaft Ass'y, Throttle	1	3.71
A011077	Shaft Ass'y, Throttle	1	3.15
A011079	Shaft Ass'y, Throttle	1	6.13
A011080	Shaft Ass'y, Throttle	1	3.48
A011081	Shaft Ass'y, Throttle	1	3.39
A011082	Shaft Ass'y, Throttle	1	3.47
A011083	Shaft Ass'y, Throttle	1	3.48
A011091	Shaft Ass'y, Throttle	1	3.53
A011096	Shaft Ass'y, Throttle	1	3.71
A011097	Shaft Ass'y, Throttle	1	3.71
A011099	Shaft Ass'y, Throttle	1	3.71
A011101	Shaft Ass'y, Throttle	1	3.71
A011103	Shaft Ass'y, Throttle	1	3.71
A011104	Shaft Ass'y, Throttle	1	3.53
A011105	Shaft Ass'y, Throttle	1	2.77
A011106	Shaft Ass'y, Throttle	1	3.71
A011107	Shaft Ass'y, Throttle	1	3.71
A011108	Shaft Ass'y, Throttle	1	3.71
A011109	Shaft Ass'y, Throttle	1	3.71
A011111	Shaft Ass'y, Throttle	1	3.71
A011112	Shaft Ass'y, Throttle	1	3.71
A011133	Shaft Ass'y, Throttle	1	3.71
A011134	Shaft Ass'y, Throttle	1	3.71
A011135	Shaft Ass'y, Throttle	1	3.71
A011136	Shaft Ass'y, Throttle	1	3.71
A011137	Shaft Ass'y, Throttle	1	3.71
A011138	Shaft Ass'y, Throttle	1	3.71
A011139	Shaft Ass'y, Throttle	1	3.71
A011140	Shaft Ass'y, Throttle	1	3.71
A011141	Shaft Ass'y, Throttle	1	3.71
A011142	Shaft Ass'y, Throttle	1	4.04
A011143	Shaft Ass'y, Throttle	1	4.04
A011145	Shaft Ass'y, Throttle	1	3.71
A011146	Shaft Ass'y, Throttle	1	3.71
A011149	Shaft Ass'y, Throttle	1	4.04
A011150	Shaft Ass'y, Throttle	1	3.86
A011151	Shaft Ass'y, Throttle	1	4.04
A011152	Shaft Ass'y, Throttle	1	3.88
A011154	Shaft Ass'y, Throttle	1	4.04
A011156	Shaft Ass'y, Throttle	1	4.04

A011158	Shaft Ass'y, Throttle	1	4.04
A011159	Shaft Ass'y, Throttle	1	3.88
A011160	Shaft Ass'y, Throttle	1	3.88
A011161	Shaft Ass'y, Throttle	1	3.88
A011162	Shaft Ass'y, Throttle	1	3.88
A011163	Shaft Ass'y, Throttle	1	3.88
A011164	Shaft Ass'y, Throttle	1	3.57
A011165	Shaft Ass'y, Throttle	1	3.88
A011166	Shaft Ass'y, Throttle	1	3.99
A011167	Shaft Ass'y, Throttle	1	3.99
A011170	Shaft Ass'y, Throttle	1	3.88
A011171	Shaft Ass'y, Throttle		
A011172	Shaft Ass'y, Throttle	1	3.71
A011175	Shaft Ass'y, Throttle	1	3.88
A011176	Shaft Ass'y, Throttle	1	3.71
A011177	Shaft Ass'y, Throttle	1	3.88
A011178	Shaft Ass'y, Throttle		
A011179	Shaft Ass'y, Throttle	1	3.71
A011180	Shaft Ass'y, Throttle	1	3.71
A011181	Shaft Ass'y, Throttle	1	3.88
A011182	Shaft Ass'y, Throttle	1	3.71
A011183	Shaft Ass'y, Throttle	1	3.71
A011184	Shaft Ass'y, Throttle	1	3.71
A011185	Shaft Ass'y, Throttle	1	3.71
A011186	Shaft Ass'y, Throttle	1	3.71
A011187	Shaft Ass'y, Throttle	1	3.71
A011188	Shaft Ass'y, Throttle	1	3.71
A011189	Shaft Ass'y, Throttle	1	3.53
A011190	Shaft Ass'y, Throttle	1	3.71
A011191	Shaft Ass'y, Throttle	1	3.71
A011192	Shaft Ass'y, Throttle	1	3.78
A011193	Shaft Ass'y, Throttle	1	3.99
A011194	Shaft Ass'y, Throttle	1	3.99
A011195	Shaft Ass'y, Throttle	1	3.99
A011196	Shaft Ass'y, Throttle	1	3.99
A011197	Shaft Ass'y, Throttle	1	4.42
A011198	Shaft Ass'y, Throttle	1	3.15
A011199	Shaft Ass'y, Throttle		
A011200	Shaft Ass'y, Throttle	1	3.88
A011203	Shaft Ass'y, Throttle	1	3.78
A011205	Shaft Ass'y, Throttle	1	3.88
A011206	Shaft Ass'y, Throttle	1	3.88
A011207	Shaft Ass'y, Throttle	1	3.88

A011208	Shaft Ass'y, Throttle	1	3.99
A011210	Shaft Ass'y, Throttle	1	3.99
A011211	Shaft Ass'y, Throttle	1	3.99
A011212	Shaft Ass'y, Throttle	1	3.99
A011213	Shaft Ass'y, Throttle	1	3.99
A011214	Shaft Ass'y, Throttle	1	3.99
A011215	Shaft Ass'y, Throttle		
A011216	Shaft Ass'y, Throttle	1	3.99
A011217	Shaft Ass'y, Airhead	1	3.49
A011218	Shaft Ass'y, Throttle	1	3.99
A011219	Shaft Ass'y, Airhead	1	3.49
A011220	Shaft Ass'y, Throttle	1	3.99
A011222	Shaft Ass'y, Throttle	1	3.88
A011223	Shaft Ass'y, Airhead	1	3.88
A011224	Shaft Ass'y, Throttle	1	3.99
A011225	Shaft Ass'y, Throttle		
A011226	Shaft Ass'y, Throttle	1	3.88
A011227	Shaft Ass'y, Throttle	1	3.99
A011229	Shaft Ass'y, Throttle	1	3.99
A011230	Shaft Ass'y, Throttle	1	3.99
A011231	Shaft Ass'y, Throttle	1	3.99
A011232	Shaft Ass'y, Throttle	1	3.99
A011233	Shaft Ass'y, Airhead	1	3.99
A011234	Shaft Ass'y, Throttle	1	3.99
A011236	Shaft Ass'y, Throttle		
A011237	Shaft Ass'y, Throttle		
A011238	Shaft Ass'y, Throttle	1	3.99
A011239	Shaft Ass'y, Throttle	1	3.99
A011240	Shaft Ass'y, Airhead	1	3.99
A011241	Shaft Ass'y, Throttle	1	3.99
A011242	Shaft Ass'y, Throttle	1	3.99
A011243	Shaft Ass'y, Throttle	1	3.99
A011244	Shaft Ass'y, Airhead	1	3.99
A011245	Shaft Ass'y, Throttle	1	3.99
A011246	Shaft Ass'y, Throttle	1	3.99
A011248	Shaft Ass'y, Throttle		
A011249	Shaft Ass'y, Throttle	1	3.99
A011250	Shaft Ass'y, Throttle	1	3.99
A011251	Shaft Ass'y, Airhead	1	3.99
A011252	Shaft Ass'y, Throttle	1	3.99
A011253	Shaft Ass'y, Throttle		
A011255	Shaft Ass'y, Throttle		
A011257	Shaft Ass'y, Throttle	1	3.99

A011258	Shaft Ass'y, Throttle	1	3.99
A011259	Shaft Ass'y, Throttle	1	3.99
A011260	Shaft Ass'y, Throttle		
A011261	Shaft Ass'y, Throttle		
A011263	Shaft Ass'y, Throttle	1	3.99
A011264	Shaft Ass'y, Throttle	1	3.99
A011268	Shaft Ass'y, Throttle	1	3.99
A011269	Shaft Ass'y, Throttle		
A011270	Shaft Ass'y, Throttle	1	3.99
A011271	Shaft Ass'y, Airhead	1	3.99
A011272	Shaft Ass'y, Throttle		
A011273	Shaft Ass'y, Throttle		
A011274	Shaft Ass'y, Throttle	1	3.99
A011281	Shaft Ass'y, Throttle	1	3.99
A011282	Shaft Ass'y, Throttle	1	3.99
A011703	Shaft Ass'y, Throttle	1	3.99
A011704	Shaft Ass'y, Throttle	1	3.99
A011705	Shaft Ass'y, Throttle	1	3.99
A011706	Shaft Ass'y, Throttle	1	3.99
A012001	Lever Ass'y, Throttle	5	11.58
A012007	Lever Ass'y, Throttle	5	9.08
A012028	Lever Ass'y, Throttle	5	9.12
A012031	Lever Ass'y, Throttle	5	9.12
A012033	Lever Ass'y, Throttle	5	9.45
A012035	Lever Ass'y, Throttle	5	9.45
A012037	Lever Ass'y, Throttle	5	9.45
A012038	Lever Ass'y, Throttle	5	9.45
A015002	Diaphragm Ass'y, Metering	10	2.80
A015005	Diaphragm Ass'y, Metering	10	3.82
A015006	Diaphragm Ass'y, Metering	10	2.80
A015007	Use A015006		
A015010	Diaphragm Ass'y, Metering	10	2.79
A015011	Diaphragm Ass'y, Metering	10	5.03
A015012	Diaphragm Ass'y, Metering	10	3.76
A015013	Diaphragm Ass'y, Metering	10	3.77
A015015	Diaphragm Ass'y, Metering	10	4.61
A015016	Diaphragm Ass'y, Metering	10	3.75
A015017	Diaphragm Ass'y, Metering	10	3.75
A015018	Diaphragm Ass'y, Metering	10	3.75
A015019	Diaphragm Ass'y, Metering	10	3.75
A015040	Diaphragm Ass'y, Metering	10	3.25
A015041	Diaphragm Ass'y, Metering	10	3.21
A015042	Diaphragm Ass'y, Metering	10	3.21

A015043	Diaphragm Ass'y, Metering	10	3.75
A015044	Diaphragm, Metering	10	2.83
A015045	Diaphragm Ass'y, Metering		
A015046	Diaphragm Ass'y, Metering		
A015047	Diaphragm Ass'y, Metering	10	3.75
A015048	Diaphragm Ass'y, Metering	10	3.75
A015049	Diaphragm Ass'y, Metering	10	3.75
A015050	Diaphragm Ass'y, Metering	10	3.75
A015051	Diaphragm Ass'y, Metering	10	3.75
A015052	Diaphragm Ass'y, Metering	10	3.75
A015053	Diaphragm Ass'y, Metering	10	2.76
A015055	Diaphragm Ass'y, Metering	10	3.21
A015056	Diaphragm Ass'y, Metering		
A015058	Diaphragm Ass'y, Metering	10	3.75
A015060	Diaphragm Ass'y, Metering		
A015061	Diaphragm Ass'y, Metering		
A015064	Diaphragm Ass'y, Metering	10	3.75
A015067	Diaphragm Ass'y, Metering		
A015069	Diaphragm Ass'y, Metering		
A015070	Diaphragm Ass'y, Metering		
A015078	Diaphragm Ass'y, Metering	10	3.75
A015701	Diaphragm Ass'y, Metering	10	2.76
A017006	Cover Ass'y, Pump		
A017008	Cover Ass'y, Pump	1	5.44
A017012	Cover Ass'y, Pump	1	5.44
A017014	Cover Ass'y, Pump	1	5.44
A017015	Cover Ass'y, Pump	1	5.44
A017016	Cover Ass'y, Pump	1	5.44
A017018	Cover Ass'y, Pump	1	5.44
A017041	Cover Ass'y, Pump		
A017043	Cover Ass'y, Pump	1	5.44
A017044	Cover Ass'y, Pump		
A017045	Cover Ass'y, Pump	1	5.44
A017046	Cover Ass'y, Pump	1	5.44
A017047	Cover Ass'y, Pump	1	5.44
A017048	Cover Ass'y, Pump	1	5.44
A017050	Cover Ass'y, Pump	1	5.44
A017051	Cover Ass'y, Pump	1	5.44
A017052	Cover Ass'y, Pump	1	5.44
A017053	Cover Ass'y, Pump		
A017701	Cover Ass'y, Pump	1	5.44
A028024	Cover Ass'y, Mtrg. Chambe	1	4.04
A028026	Cover Ass'y, Mtrg. Chambe	1	4.04

A028027	Cover Ass'y, Mtrg. Chamber		
A028029	Cover Ass'y, Mtrg. Chamber		
A028030	Cover Ass'y, Mtrg. Chamber		
A028032	Cover Ass'y, Mtrg. Chamber		
A028033	Cover Ass'y, Mtrg. Chamber		
A028034	Cover Ass'y, Mtrg. Chamber		
A030001	Screw Ass'y, Main Mixture	1	3.70
A030002	Screw Ass'y, Main Mixture		
A030003	Screw Ass'y, Main Mixture		
A031002	Screw Ass'y, Idle Mixture		
A031003	Screw Ass'y, Idle Mixture		
A031005	Screw Ass'y, Idle Mixture		
A031007	Screw Ass'y, Idle Mixture		
A031008	Screw Ass'y, Idle Mixture		
A031011	Screw Ass'y, Idle Mixture		
A031012	Screw Ass'y, Idle Mixture		
A031017	Screw Ass'y, Idle Mixture		
A031018	Screw Ass'y, Idle Mixture		
A031019	Screw Ass'y, Idle Mixture	1	3.70
A031020	Screw Ass'y, Idle Mixture		
A031024	Screw Ass'y, Idle Mixture		
A031025	Screw Ass'y, Idle Mixture		
A031026	Screw Ass'y, Idle Mixture		
A031027	Screw Ass'y, Idle Mixture		
A031028	Screw Ass'y, Idle Mixture		
A031029	Screw Ass'y, Idle Mixture		
A031030	Screw Ass'y, Idle Mixture		
A031031	Screw Ass'y, Idle Mixture		
A031066	Screw, Idle Mixture	1	3.70
A031067	Screw, Idle Mixture	1	3.70
A031082	Screw Ass'y, Idle Mixture	1	3.70
A031084	Screw Ass'y, Idle Mixture	1	3.70
A031085	Screw Ass'y, Idle Mixture		
A035001	Screw Ass'y, Throttle Adjust		
A035002	Screw Ass'y, Throttle Adjust		
A035003	Screw Ass'y, Throttle Adjust		
A035004	Screw Ass'y, Throttle Adjust		
A035005	Screw Ass'y, Throttle Adjust		
A035006	Screw Ass'y, Throttle Adjust		
A041001	Shaft Ass'y, Choke	1	2.58
A041004	Shaft Ass'y, Choke	1	3.47
A041005	Discontinued		
A041010	Shaft Ass'y, Choke	1	3.38

A041011	Shaft Ass'y, Choke	1	4.24
A041015	Shaft Ass'y, Choke	1	4.05
A041016	Shaft Ass'y, Choke	1	3.61
A041017	Shaft Ass'y, Choke	1	4.01
A041019	Shaft Ass'y, Choke	1	4.01
A041020	Shaft Ass'y, Choke	1	6.30
A041021	Shaft Ass'y, Choke	1	4.00
A041022	Shaft Ass'y, Choke	1	6.08
A041029	Shaft Ass'y, Choke	1	4.76
A041031	Shaft Ass'y, Choke	1	6.06
A041032	Shaft Ass'y, Choke	1	4.62
A041035	Shaft Ass'y, Choke	1	5.83
A041039	Shaft Ass'y, Choke	1	5.07
A041043	Shaft Ass'y, Choke	1	4.87
A041044	Shaft Ass'y, Choke	1	5.07
A041047	Shaft Ass'y, Choke	1	5.83
A041048	Shaft Ass'y, Choke	1	5.07
A041049	Shaft Ass'y, Choke	1	5.07
A041050	Shaft Ass'y, Choke	1	4.24
A041051	Shaft Ass'y, Choke	1	5.07
A041073	Shaft Ass'y, Choke	1	5.07
A041075	Shaft Ass'y, Choke	1	5.07
A041076	Shaft Ass'y, Choke	1	5.07
A041077	Shaft Ass'y, Choke	1	5.52
A041079	Shaft Ass'y, Choke	1	5.07
A041081	Shaft Ass'y, Choke	1	6.00
A041082	Shaft Ass'y, Choke	1	5.07
A041083	Shaft Ass'y, Choke	1	5.07
A041084	Shaft Ass'y, Choke	1	5.07
A041085	Shaft Ass'y, Choke	1	5.07
A041086	Shaft Ass'y, Choke	1	5.07
A041087	Shaft Ass'y, Choke	1	5.07
A041089	Shaft Ass'y, Choke	1	5.07
A041091	Shaft Ass'y, Choke	1	5.07
A041092	Shaft Ass'y, Choke	1	5.07
A041093	Shaft Ass'y, Choke	1	5.07
A041094	Shaft Ass'y, Choke	1	5.07
A041095	Shaft Ass'y, Choke	1	5.07
A041096	Shaft Ass'y, Choke	1	5.07
A041097	Shaft Ass'y, Choke	1	5.07
A041098	Shaft Ass'y, Choke	1	5.58
A041099	Shaft Ass'y, Choke	1	5.07
A041100	Shaft Ass'y, Choke	1	5.07

A041101	Shaft Ass'y, Choke	1	5.07
A041102	Shaft Ass'y, Choke	1	5.07
A041103	Shaft Ass'y, Choke	1	5.07
A041105	Shaft Ass'y, Choke	1	5.07
A041107	Shaft Ass'y, Choke	1	5.07
A041108	Shaft Ass'y, Choke	1	5.58
A041110	Shaft Ass'y, Choke	1	5.07
A041111	Shaft Ass'y, Choke	1	5.07
A041112	Shaft Ass'y, Choke		
A041113	Shaft Ass'y, Choke	1	5.07
A041115	Shaft Ass'y, Choke	1	5.58
A041116	Shaft Ass'y, Choke	1	5.58
A041118	Shaft Ass'y, Choke	1	5.07
A041119	Shaft Ass'y, Choke	1	5.07
A041120	Shaft Ass'y, Choke	1	5.58
A041121	Shaft Ass'y, Choke	1	5.58
A041122	Shaft Ass'y, Choke	1	5.58
A041123	Shaft Ass'y, Choke	1	5.58
A041124	Shaft Ass'y, Choke	1	5.58
A041125	Shaft Ass'y, Choke	1	5.58
A041126	Shaft Ass'y, Choke		
A041127	Shaft Ass'y, Choke	1	5.58
A041128	Shaft Ass'y, Choke		
A041129	Shaft Ass'y, Choke	1	5.58
A041130	Shaft Ass'y, Choke	1	5.58
A041134	Shaft Ass'y, Choke	1	5.58
A041135	Shaft Ass'y, Choke	1	5.58
A041139	Shaft Ass'y, Choke	1	5.58
A041140	Shaft Ass'y, Choke	1	5.58
A041143	Shaft Ass'y, Choke		
A041701	Shaft Ass'y, Choke	1	5.58
A041702	Shaft Ass'y, Choke	1	5.58
A042027	Lever Ass'y, Choke	1	5.58
A042029	Lever Ass'y, Choke	1	5.58
A042030	Lever Ass'y, Choke	1	5.58
A042701	Lever Ass'y, Choke	1	5.58
A049026	Body Ass'y, Start Pump	1	5.03
A049029	Body Ass'y, Pump	1	9.09
A049030	Body Ass'y, Oil Pump	1	8.11
A049033	Body Ass'y, Pump	1	5.03
A049035	Body Ass'y, Pump	1	9.09
A049036	Body Ass'y, Pump	1	9.09
A049037	Body Ass'y, Pump	1	9.09

A053001	Ass'y, Plunger	1	7.17
A053022	Ass'y Starter, Plunger	1	5.03
A056001	Discontinued		
A056004	Base Ass'y, Primer	1	11.97
A056005	Base Ass'y, Primer	1	13.34
A056007	Base Ass'y, Primer	1	11.64
A056009	Discontinued		
A056011	Base Ass'y, Primer	1	11.71
A056012	Base Ass'y, Primer	1	11.71
A056013	External Primer Ass'y	1	3.29
A056014	Discontinued		
A056015	Base Ass'y, Primer	1	13.34
A056025	Discontinued		
A056026	Base Ass'y, Primer	1	13.34
A056028	Base Ass'y, Primer	1	13.34
A056050	Base Ass'y, Primer	1	13.34
A056055	Base Ass'y, Primer	1	13.34
A056056	Base Ass'y, Primer	1	13.34
A056058	Base Ass'y, Primer	1	12.83
A056062	Base Ass'y, Primer	1	13.34
A056064	Base Ass'y, Primer	1	13.34
A056067	Base Ass'y, Primer	1	13.34
A056069	Base Ass'y, Primer	1	13.34
A056070	Base Ass'y, Primer	1	13.34
A056071	Base Ass'y, Primer	1	13.34
A056072	Base Ass'y, Primer	1	13.34
A056073	Base Ass'y, Primer	1	13.34
A056074	Base Ass'y, Primer	1	13.34
A056075	Base Ass'y, Primer	1	13.34
A056076	Base Ass'y, Primer	1	13.34
A056077	Base Ass'y, Primer	1	13.34
A056078	Base Ass'y, Primer	1	13.34
A056079	Base Ass'y, Primer	1	13.34
A056080	Base Ass'y, Primer		
A056081	Base Ass'y, Primer		
A056082	Base Ass'y, Primer	1	13.34
A056083	Base Ass'y, Primer		
A056084	Base Ass'y, Primer	1	13.34
A056085	Base Ass'y, Primer	1	13.34
A056086	Base Ass'y, Primer	1	13.34
A056087	Base Ass'y, Primer	1	13.34
A056088	Base Ass'y, Primer		
A056089	Base Ass'y, Primer	1	13.34

A056093	Base Ass'y, Primer	1	13.34
A056095	Base Ass'y, Primer	1	13.34
A056096	Base Ass'y, Primer	1	13.34
A056098	Base Ass'y, Primer	1	13.34
A056099	Base Ass'y, Primer	1	13.34
A056100	Base Ass'y, Primer	1	13.34
A056102	External Primer Ass'y	1	4.75
A056103	Base Ass'y, Primer		
A056105	Base Ass'y, Primer	1	13.34
A056106	Base Ass'y, Primer		
A056107	Base Ass'y, Primer	1	13.34
A056108	Base Ass'y, Primer	1	13.34
A056112	Base Ass'y, Primer	1	13.34
A056113	Base Ass'y, Primer		
A056116	Base Ass'y, Primer		
A056119	Base Ass'y, Primer		
A056123	Base Ass'y, Primer		
A056125	Base Ass'y, Primer	1	13.34
A056126	Base Ass'y, Primer		
A056127	Base Ass'y, Primer		
A056128	Base Ass'y, Primer		
A056130	Base Ass'y, Primer		
A056131	Base Ass'y, Primer		
A056132	Base Ass'y, Primer		
A056134	Base Ass'y, Primer		
A056135	Base Ass'y, Primer		
A056136	Base Ass'y, Primer		
A056137	Base Ass'y, Primer		
A056140	Base Ass'y, Primer		
A056148	Base Ass'y, Primer	1	13.34
A059001	Governor Ass'y	1	5.31
A059002	Governor Ass'y	1	5.31
A059004	Governor Ass'y	1	5.52
A059005	Governor Ass'y	1	5.52
A059007	Governor Ass'y	1	5.52
A059011	Governor Ass'y	1	5.52
A059033	Governor Ass'y	1	5.52
A059034	Governor Ass'y	1	5.52
A059036	Governor Ass'y	1	5.75
A061002	Limiter Ass'y		
A061003	Limiter Ass'y		
A078001	Cover Ass'y, Rotor	1	19.87
A078003	Cover Ass'y, Rotor	1	19.87

A078004	Cover Ass'y, Rotor	1	19.87
A078005	Cover Ass'y, Rotor	1	19.87
A078006	Cover Ass'y, Rotor	1	19.87
A078007	Cover Ass'y, Rotor	1	19.87
A078008	Cover Ass'y, Rotor	1	19.87
A078009	Cover Ass'y, Rotor	1	19.87
A078010	Cover Ass'y, Rotor	1	19.87
A078011	Cover Ass'y, Rotor	1	19.87
A078012	Cover Ass'y, Rotor	1	19.87
A078013	Cover Ass'y, Rotor	1	19.87
A078014	Cover Ass'y, Rotor	1	19.87
A078016	Cover Ass'y, Rotor	1	19.87
A078018	Cover Ass'y, Rotor	1	19.87
A078019	Cover Ass'y, Rotor	1	19.87
A078020	Cover Ass'y, Rotor	1	19.87
A078023	Cover Ass'y, Rotor	1	19.87
A078024	Cover Ass'y, Rotor	1	19.87
A080002	Screw Ass'y, Cable	1	3.99
A088001	Air Cleaner Ass'y	1	18.32
A088002	Body Ass'y, Airhead	1	9.71
A088003	Body Ass'y, Airhead	1	9.71
A088004	Body Ass'y, Airhead	1	9.71
A088006	Body Ass'y, Airhead	1	9.71
A088010	Body Ass'y, Airhead	1	9.71
A088012	Body Ass'y, Airhead	1	9.71
A088701	Body Ass'y, Airhead	1	9.71
C1-17-02,A	Use C1-M2B		
C1-M2B	Discontinued		
C1M-EL28, A-B	Use C1M-EL28B	1	56.84
C1M-EL35	Carburetor	1	56.04
C1M-EL37,A-B	Use C1M-EL37B	1	43.69
C1M-EL40A	Carburetor	1	57.03
C1M-EL40B-G	Carb w/module		
C1M-EL44	Carb w/module		
C1M-FR1, A-B	Use C1M-FR1B	1	66.37
C1M-H57	Carburetor	1	41.80
C1M-H58, A-D	Use C1M-H58D	1	46.61
C1M-H65	Carburetor	1	43.33
C1M-K37, A-D	Use C1M-K37D	1	49.67
C1M-K49, A-C	Use C1M-K49C	1	51.24
C1M-K76	Carburetor	1	49.28
C1M-K77	Carburetor	1	48.80
C1M-S141,A-D	Use C1M-S141D		

C1M-S142,A-D	Use C1M-S142D		
C1M-S144,A-B	Use C1M-S144B		
C1M-S145,A-B	Use C1M-S145B		
C1M-S146,A-B	Use C1M-S146B		
C1M-S151,A-B	Use C1M-S151B		
C1M-W26, A-C	Use C1M-W26C	1	48.25
C1M-W44	Carburetor	1	50.87
C1M-W47	Carburetor	1	36.53
C1Q-DM10, A-B	Use C1Q-DM10B	1	49.99
C1Q-DM13, A-B	Use C1Q-DM13B	1	56.53
C1Q-DM14, A	Use C1Q-DM14A	1	53.32
C1Q-DM15,A	Use C1Q-DM15A	1	50.35
C1Q-DM16	Carburetor	1	56.52
C1Q-DM3	Discontinued		
C1Q-DM6, A	Use C1Q-DM6A	1	45.02
C1Q-DM7, A	Use C1Q-DM7A	1	45.02
C1Q-DM8, A-B	Use C1Q-DM8B	1	49.59
C1Q-DM9, A-B	Use C1Q-DM9B	1	49.59
C1Q-E10	Carburetor	1	42.23
C1Q-E12	Carburetor	1	43.46
C1Q-E3	Carburetor	1	58.00
C1Q-E4	Carburetor	1	50.38
C1Q-E5, A-B	Use C1Q-E5B	1	50.28
C1Q-E6, A	Use C1Q-E6A	1	42.23
C1Q-E7, A	Use C1Q-E7A	1	42.23
C1Q-EL1	Carburetor	1	50.38
C1Q-EL10	Carburetor	1	49.12
C1Q-EL12	Carburetor	1	47.78
C1Q-EL13	Carburetor	1	47.78
C1Q-EL14, A	Use C1Q-EL14A	1	47.31
C1Q-EL19, A-C	Use C1Q-EL19C	1	44.87
C1Q-EL20, A-C	Use C1Q-EL20C	1	48.02
C1Q-EL21, A	Use C1Q-EL21A	1	47.85
C1Q-EL22, A	Use C1Q-EL22A	1	47.85
C1Q-EL23, A	Use C1Q-EL23A	1	45.41
C1Q-EL24, A	Use C1Q-EL24A	1	41.64
C1Q-EL25, A	Use C1Q-EL25A	1	43.14
C1Q-EL26, A	Use C1Q-EL26A	1	46.92
C1Q-EL27	Carburetor	1	43.61
C1Q-EL30, A-B	Use C1Q-EL30B	1	39.68
C1Q-EL33, A	Use C1Q-EL33A	1	43.92
C1Q-EL34	Carburetor	1	46.75
C1Q-EL36,A-B	Use C1Q-EL36B	1	41.57

C1Q-EL38	Carburetor	1	41.31
C1Q-EL39,A	Use C1Q-EL39A	1	41.24
C1Q-EL45	Carburetor	1	40.47
C1Q-EL5, A	Discontinued		
C1Q-EL6	Carburetor	1	48.31
C1Q-EL7	Carburetor	1	47.02
C1Q-H14, A-B	Discontinued		
C1Q-H17	Carburetor	1	59.66
C1Q-H17, A-B	Use C1Q-H17B	1	44.19
C1Q-H17, C-D	Use C1Q-H17D	1	42.49
C1Q-H19, A-C	Use C1Q-H19C	1	52.40
C1Q-H27	Carburetor	1	46.30
C1Q-H32, A	Discontinued		
C1Q-H35	Discontinued		
C1Q-H42	Discontinued		
C1Q-H43	Carburetor	1	46.00
C1Q-H44	Carburetor	1	43.23
C1Q-H45	Carburetor	1	48.14
C1Q-H64	Carburetor	1	46.92
C1Q-K64, A	Use C1Q-K64A	1	54.16
C1Q-K73, A	Use C1Q-K73A	1	55.26
C1Q-K79	Carburetor	1	62.58
C1Q-M27, A-C	Use C1Q-M27C	1	47.96
C1Q-M27D	Carburetor	1	40.42
C1Q-M28D	Discontinued		
C1Q-M31	Carburetor	1	42.91
C1Q-M33, A-D	Discontinued		
C1Q-M36, A	Use C1Q-M36A	1	40.69
C1Q-M39	Carburetor	1	45.27
C1Q-M41	Carburetor	1	47.54
C1Q-M43	Carburetor	1	36.76
C1Q-M44	Carburetor	1	36.92
C1Q-P18, A	Use C1Q-P18A	1	43.69
C1Q-P22, A-C	Use C1Q-P22C	1	38.18
C1Q-P24	Carburetor	1	42.51
C1Q-P26, A-C	Use C1Q-P26C	1	39.36
C1Q-P8	Discontinued		
C1Q-S100,A	Use C1Q-S100A		
C1Q-S101, A	Use C1Q-S101A		
C1Q-S102,A	Use C1Q-S102A		
C1Q-S103	Discontinued		
C1Q-S104	Carburetor		
C1Q-S105	Discontinued		

C1Q-S106,A	Discontinued
C1Q-S107,A	Use C1Q-S107A
C1Q-S108, A	Discontinued
C1Q-S109, A	Discontinued
C1Q-S11, C-G	Use C1Q-S11G
C1Q-S110,A-C	Use C1Q-S110C
C1Q-S111	Carburetor
C1Q-S112,A	Use C1Q-S112A
C1Q-S113	Discontinued
C1Q-S114	Carburetor
C1Q-S115,A-B	Use C1Q-S115B
C1Q-S116,A	Use C1Q-S116A
C1Q-S117	Discontinued
C1Q-S118,A-C	Use C1Q-S118C
C1Q-S119,A-B	Use C1Q-S119B
C1Q-S120,A-B	Use C1Q-S120B
C1Q-S121,A-B	Use C1Q-S121B
C1Q-S122,A-B	Use C1Q-S122B
C1Q-S123,A-B	Use C1Q-S123B
C1Q-S124,A	Use C1Q-S124A
C1Q-S125	Carburetor
C1Q-S126,A	Use C1Q-S126A
C1Q-S127,A	Use C1Q-S127A
C1Q-S128,A	Use C1Q-S128A
C1Q-S129,A	Use C1Q-S129A
C1Q-S130,A-B	Use C1Q-S130B
C1Q-S131,A-B	Use C1Q-S131B
C1Q-S132,A-B	Use C1Q-S132B
C1Q-S133,A	Use C1Q-S133A
C1Q-S134	Carburetor
C1Q-S135	Carburetor
C1Q-S136	Carburetor
C1Q-S137,A	Use C1Q-S137A
C1Q-S138	Carburetor
C1Q-S139	Carburetor
C1Q-S140,A	Use C1Q-S140A
C1Q-S143	Carburetor
C1Q-S150	Carburetor
C1Q-S152	Carburetor
C1Q-S153	Carburetor
C1Q-S154	Carburetor
C1Q-S155	Carburetor
C1Q-S156	Carburetor

C1Q-S157	Carburetor		
C1Q-S159	Carburetor		
C1Q-S16, A	Use C1Q-S16A	1	71.88
C1Q-S160	Carburetor		
C1Q-S161	Carburetor		
C1Q-S162	Carburetor		
C1Q-S165	Carburetor		
C1Q-S166	Carburetor		
C1Q-S167,A	Use C1Q-S167A		
C1Q-S169	Carburetor		
C1Q-S170	Carburetor		
C1Q-S171,A	Use C1Q-S171A		
C1Q-S178,A-C	Use C1Q-S178C		
C1Q-S179,A-C	Use C1Q-S179C		
C1Q-S180,A-C	Use C1Q-S180C		
C1Q-S183	Carburetor		
C1Q-S184	Carburetor		
C1Q-S185	Carburetor		
C1Q-S186	Carburetor		
C1Q-S187	Carburetor		
C1Q-S190	Carburetor		
C1Q-S191	Carburetor		
C1Q-S192	Carburetor		
C1Q-S28, A-D	Use C1Q-S28D	1	53.21
C1Q-S29, A-C	Use C1Q-S29C		
C1Q-S30, A-C	Use C1Q-S30C		
C1Q-S32	Carburetor		
C1Q-S33, A-B	Use C1Q-S33B		
C1Q-S34, A-H	Use C1Q-S34H		
C1Q-S35, A-B	Use C1Q-S35B		
C1Q-S37, A-B	Use C1Q-S37B		
C1Q-S41, A-B	Use C1Q-S41B		
C1Q-S42, A-B	Use C1Q-S42B		
C1Q-S43, A-B	Use C1Q-S43B		
C1Q-S46, A-B	Use C1Q-S46B		
C1Q-S47	Carburetor		
C1Q-S48, A	Use C1Q-S48A		
C1Q-S51, A-D	Use C1Q-S51D		
C1Q-S54	Carburetor		
C1Q-S55	Carburetor		
C1Q-S56	Carburetor		
C1Q-S57, A-B	Use C1Q-S57B		
C1Q-S58	Carburetor		

C1Q-S59,A	Discontinued		
C1Q-S60	Discontinued		
C1Q-S61, A-E	Discontinued		
C1Q-S62	Carburetor		
C1Q-S63, A	Discontinued		
C1Q-S64	Carburetor		
C1Q-S68, A-D	Use C1Q-S68D		
C1Q-S69, A	Discontinued		
C1Q-S70,A	Discontinued		
C1Q-S71	Discontinued		
C1Q-S72, B	Use C1Q-S72B		
C1Q-S73	Discontinued		
C1Q-S74, A-D	Use C1Q-S74D		
C1Q-S75, A-B	Use C1Q-S75B		
C1Q-S76, A-B	Use C1Q-S76B		
C1Q-S77, A-B	Use C1Q-S77B		
C1Q-S78	Discontinued		
C1Q-S79	Carburetor		
C1Q-S80B-C	Use C1Q-S80C		
C1Q-S81	Discontinued		
C1Q-S82	Discontinued		
C1Q-S83	Discontinued		
C1Q-S84, A-C	Use C1Q-S84C		
C1Q-S85, A-C	Use C1Q-S85C		
C1Q-S86, A-C	Discontinued		
C1Q-S87, A-C	Use C1Q-S87C		
C1Q-S88	Discontinued		
C1Q-S89, A-C	Use C1Q-S89C		
C1Q-S90, A-B	Use C1Q-S90B		
C1Q-S91,A	Use C1Q-S91A		
C1Q-S92,A	Use C1Q-S92A		
C1Q-S93	Carburetor		
C1Q-S94	Discontinued		
C1Q-S95	Discontinued		
C1Q-S96, A-B	Discontinued		
C1Q-S97,A	Use C1Q-S97A		
C1Q-S98,A-B	Use C1Q-S98B		
C1Q-S99, A	Use C1Q-S99A		
C1Q-SK10	Carburetor	1	72.86
C1Q-SK15	Carburetor	1	82.28
C1Q-SK16	Carburetor	1	77.12
C1Q-SK5	Carburetor	1	50.48
C1Q-SK6, A	Discontinued		

C1Q-SK8	Carburetor	1	62.22
C1Q-SK9	Discontinued		
C1Q-W11, A-G	Use C1Q-W11G	1	33.46
C1Q-W14	Carburetor	1	33.91
C1Q-W14A	Carburetor	1	32.66
C1Q-W15	Carburetor	1	46.83
C1Q-W20, A-B	Use C1Q-W20B	1	33.46
C1Q-W29, A-E	Use C1Q-W29E	1	37.79
C1Q-W31, A-B	Use C1Q-W31B	1	40.15
C1Q-W34, A	Use C1Q-W34A	1	41.33
C1Q-W35, A	Use C1Q-W35A	1	42.35
C1Q-W36, A	Use C1Q-W36A	1	42.51
C1Q-W37	Carburetor	1	35.55
C1Q-W38	Carburetor	1	36.48
C1Q-W39	Carburetor	1	38.65
C1Q-W40,A	Use C1Q-W40A	1	39.51
C1Q-W41,A	Use C1Q-W41A	1	39.66
C1Q-W5, A-C	Discontinued		
C1Q-W6, A-C	Discontinued		49.20
C1Q-W8	Carburetor	1	40.48
C1Q-W9	Carburetor	1	35.10
C1Q-W9, A-E	Use C1Q-W9E	1	37.08
C1Q-Z4	Carburetor	1	58.80
C1Q-Z5	Carburetor	1	57.55
C1Q-Z6,A	Use C1Q-Z6A	1	62.97
C1Q-Z7,A	Use C1Q-Z7A	1	57.03
C1S-E1	Discontinued		
C1S-H2A	Discontinued		
C1S-H4, A-C	Use C1S-H4C	1	45.67
C1S-H6A	Discontinued		
C1S-H7	Discontinued		
C1S-H8, A	Discontinued		
C1S-K1, A-D	Use C1S-K1D	1	46.09
C1S-M12	Discontinued		
C1S-M13	Carburetor	1	43.94
C1S-M9	Discontinued		
C1S-S1, A-C	Use C1S-S1C	1	45.67
C1S-S3, A-G	Use C1S-S3G	1	57.18
C1S-SK1, SK2	Use C1Q-SK5		
C1S-Z1, A-D	Discontinued		
C1T-EL41A	Carburetor, Airhead	1	44.77
C1T-W33,A-C	Use C1T-W33C	1	48.38
C1U Simple Start®			

C1U-D1B	Carburetor	1	39.66
C1U-DM4, A-C	Use C1U-DM4C	1	51.40
C1U-FD1	Carburetor	1	56.15
C1U-H10, A-B	Use C1U-H10B	1	50.50
C1U-H11, A-K	Use C1U-H11K	1	50.02
C1U-H12, A	Use C1U-H12A	1	50.38
C1U-H12, B-D	Use C1U-H12D	1	52.40
C1U-H13, A-E	Use C1U-H13E	1	53.91
C1U-H18, A-D	Use C1U-H18D	1	51.47
C1U-H28	Carburetor	1	49.87
C1U-H30, B	Use C1U-H30B	1	46.82
C1U-H31, A-C	Use C1U-H31C	1	39.48
C1U-H33	Carburetor	1	41.43
C1U-H36	Carburetor	1	36.54
C1U-H37	Carburetor	1	41.39
C1U-H39, A	Use C1U-H39A	1	37.01
C1U-H40	Carburetor	1	45.23
C1U-H41	Carburetor	1	36.84
C1U-H46, A	Use C1U-H46A	1	43.61
C1U-H46, A	See C1U Simple Start®		
C1U-H47	Carburetor	1	32.59
C1U-H48, A	Use C1U-H48A	1	34.40
C1U-H49	Simple Start® Carburetor	1	46.36
C1U-H49	See C1U Simple Start®		
C1U-H60, A-E	Use C1U-H60E	1	35.74
C1U-H61, A	Use C1U-H61A	1	39.36
C1U-H62A	Carburetor	1	38.88
C1U-K12	Discontinued		
C1U-K13	Discontinued		
C1U-K15, A-B	Discontinued		
C1U-K21, A-B	Discontinued		
C1U-K22, A	Use C1U-K22A	1	45.73
C1U-K28, A	Discontinued		
C1U-K30, A	Use C1U-K30A	1	45.73
C1U-K36, A	Use C1U-K36A	1	57.95
C1U-K39, A-B	Use C1U-K39B	1	65.49
C1U-K41, A-B	Use C1U-K41B	1	52.61
C1U-K42, A-B	Use C1U-K42B	1	44.17
C1U-K43, A-B	Use C1U-K43B	1	46.92
C1U-K44, A-B	Use C1U-K44B	1	46.92
C1U-K47	Carburetor	1	52.07
C1U-K52	Carburetor	1	50.26
C1U-K53, A-B	Use C1U-K53B	1	54.03

C1U-K54, A	Use C1U-K54A	1	59.03
C1U-K55	Carburetor	1	53.46
C1U-K58	Carburetor	1	44.87
C1U-K59	Carburetor	1	51.09
C1U-K62	Carburetor	1	48.65
C1U-K68	Carburetor	1	42.67
C1U-K7, A	Use C1U-K7A	1	41.10
C1U-K78	Carburetor	1	41.17
C1U-K81,A-B	Use C1U-K81B	1	46.14
C1U-K82	Carburetor	1	48.88
C1U-K83	Carburetor	1	63.99
C1U-M20	Carburetor	1	41.24
C1U-M21, A-B	Use C1U-M21B	1	45.73
C1U-M21C	Discontinued		
C1U-M29, A-E	Discontinued		
C1U-M32, A	Use C1U-M32A	1	50.00
C1U-M32, B-C	Use C1U-M32C	1	41.05
C1U-M37, A	Discontinued		
C1U-M38	Carburetor	1	51.41
C1U-M40	Carburetor	1	44.71
C1U-M42	Carburetor	1	42.35
C1U-P10, A	Use C1U-P10A	1	40.08
C1U-P11, A-B	Use C1U-P11B	1	41.77
C1U-P12, A	Use C1U-P12A	1	38.23
C1U-P14, A	Use C1U-P14A	1	38.23
C1U-P17	Carburetor	1	29.83
C1U-P21, A-B	Use C1U-P21B	1	30.93
C1U-P23	Carburetor	1	28.65
C1U-P27	Simple Start® Carburetor	1	35.95
C1U-P27	See C1U Simple Start®		
C1U-P6, A	Discontinued		
C1U-SK11	Carburetor	1	66.56
C1U-SK12	Carburetor	1	56.81
C1U-SK13, A	Use C1U-SK13A	1	69.51
C1U-SK14	Carburetor	1	73.11
C1U-SK17	Carburetor	1	60.73
C1U-U1	Carburetor	1	46.20
C1U-W10, B-C	Use C1U-W10C	1	32.27
C1U-W12, A-B	Use C1U-W12B	1	37.15
C1U-W13, A-B	Use C1U-W13B	1	38.03
C1U-W16, B-C	Use C1U-W16C	1	36.05
C1U-W17, A	Use C1U-W17A	1	42.28
C1U-W17, A	See C1U Simple Start®		

C1U-W18, A	Use C1U-W18A	1	32.98
C1U-W19	Simple Start® Carburetor	1	42.75
C1U-W19	See C1U Simple Start®		
C1U-W22	Carburetor	1	43.37
C1U-W24	Carburetor	1	32.98
C1U-W32, A	Use C1U-W32A	1	36.20
C1U-W4, A-E	Use C1U-W4E	1	45.27
C1U-W43,A-B	Use C1U-W43B	1	37.35
C1U-W45	Carburetor	1	40.03
C1U-W46	Carburetor	1	31.71
C1U-W49	Carburetor	1	40.25
C1U-W7, A-D	Use C1U-W7D	1	43.62
C2-L1, A	Use C2-L1A	1	55.95
C2-M3A	Discontinued		
C3A-H15, A-B	Use C3A-H15B	1	53.71
C3A-S19	Carburetor	1	54.36
C3A-S25	Discontinued		
C3A-S26	Discontinued		
C3A-S27, A-D	Use C3A-S27D		
C3A-S31, A-E	Use C3A-S31E		
C3A-S38, A-B	Use C3A-S38B		
C3A-S39, A-B	Use C3A-S39B		
C3A-S4C	Discontinued		
C3A-S65	Carburetor		
C3-E8, A	Use C3-E8A	1	58.97
C3-E9, A	Use C3-E9A	1	60.53
C3-EL15, A	Use C3-EL15A	1	47.31
C3-EL16, A	Use C3-EL16A	1	47.31
C3-EL17, A-B	Use C3-EL17B	1	46.44
C3-EL18, A-B	Use C3-EL18B	1	47.95
C3-EL29, A-C	Use C3-EL29C	1	62.74
C3-EL32	Carburetor	1	40.99
C3-EL42	Carburetor	1	43.40
C3-EL43, A	Use C3-EL43A	1	58.04
C3M-DM11, A-D	Use C3M-DM11D	1	59.90
C3M-DM12, A-B	Use C3M-DM12B	1	62.16
C3M-EL2, A-C	Use C3M-EL2C	1	52.89
C3M-FJ5, A	Use C3M-FJ5A	1	288.01
C3M-K33, A-D	Use C3M-K33D	1	86.36
C3M-K74	Carburetor	1	80.22
C3M-K80	Carburetor	1	82.03
C3M-S5, A-G	Discontinued		
C3-S148	Carburetor		

C3-S149	Carburetor		
CDMAN	Service Manual on CD	1	3.82
G1L-E11, A	Use G1L-E11A	1	57.55
GND-1	Gasket & Diaphragm Kit	1	6.50
GND-101	Gasket & Diaphragm Kit		
GND-104	Gasket & Diaphragm Kit		
GND-105	Gasket & Diaphragm Kit	1	6.75
GND-106	Gasket & Diaphragm Kit	1	6.75
GND-12	Gasket & Diaphragm Kit	1	4.67
GND-17	Gasket & Diaphragm Kit	1	4.49
GND-18	Gasket & Diaphragm Kit	1	5.45
GND-19	Gasket & Diaphragm Kit	1	5.03
GND-2	Gasket & Diaphragm Kit	1	6.50
GND-20	Gasket & Diaphragm Kit	1	5.03
GND-21	Gasket & Diaphragm Kit	1	5.03
GND-24	Gasket & Diaphragm Kit	1	5.03
GND-25	Gasket & Diaphragm Kit	1	5.03
GND-26	Gasket & Diaphragm Kit	1	5.03
GND-27	Gasket & Diaphragm Kit	1	5.03
GND-28	Gasket & Diaphragm Kit	1	5.03
GND-3	Gasket & Diaphragm Kit	1	5.03
GND-30	Gasket & Diaphragm Kit	1	6.50
GND-31	Gasket & Diaphragm Kit	1	5.03
GND-32	Gasket & Diaphragm Kit	1	5.03
GND-33	Gasket & Diaphragm Kit	1	5.03
GND-35	Gasket & Diaphragm Kit	1	5.03
GND-38	Gasket & Diaphragm Kit	1	5.03
GND-39	Gasket & Diaphragm Kit	1	5.03
GND-4	Gasket & Diaphragm Kit	1	5.03
GND-40	Gasket & Diaphragm Kit	1	5.03
GND-41	Gasket & Diaphragm Kit	1	5.03
GND-43	Gasket & Diaphragm Kit	1	6.50
GND-44	Gasket & Diaphragm Kit	1	5.03
GND-47	Gasket & Diaphragm Kit	1	5.03
GND-48	Gasket & Diaphragm Kit	1	5.03
GND-49	Gasket & Diaphragm Kit	1	5.68
GND-5	Gasket & Diaphragm Kit	1	5.03
GND-50	Gasket & Diaphragm Kit	1	5.03
GND-51	Gasket & Diaphragm Kit	1	5.03
GND-52	Gasket & Diaphragm Kit	1	5.03
GND-53	Gasket & Diaphragm Kit	1	5.03
GND-54	Gasket & Diaphragm Kit	1	5.03
GND-55	Gasket & Diaphragm Kit	1	5.74

GND-56	Gasket & Diaphragm Kit	1	5.03
GND-57	Gasket & Diaphragm Kit	1	5.03
GND-58	Gasket & Diaphragm Kit	1	5.03
GND-59	Gasket & Diaphragm Kit	1	5.03
GND-6	Gasket & Diaphragm Kit	1	5.03
GND-61	Gasket & Diaphragm Kit	1	5.03
GND-62	Gasket & Diaphragm Kit	1	4.80
GND-63	Gasket & Diaphragm Kit	1	6.24
GND-64	Gasket & Diaphragm Kit	1	5.24
GND-65	Gasket & Diaphragm Kit	1	5.03
GND-66	Gasket & Diaphragm Kit	1	5.03
GND-67	Gasket & Diaphragm Kit	1	5.03
GND-68	Gasket & Diaphragm Kit	1	5.03
GND-7	Gasket & Diaphragm Kit	1	4.49
GND-70	Gasket & Diaphragm Kit	1	5.68
GND-71	Gasket & Diaphragm Kit	1	5.03
GND-72	Gasket & Diaphragm Kit	1	5.03
GND-73	Gasket & Diaphragm Kit	1	6.50
GND-74	Gasket & Diaphragm Kit	1	6.16
GND-75	Gasket & Diaphragm Kit	1	5.74
GND-77	Gasket & Diaphragm Kit	1	5.03
GND-78	Gasket & Diaphragm Kit	1	5.68
GND-8	Gasket & Diaphragm Kit	1	5.03
GND-80	Gasket & Diaphragm Kit	1	5.74
GND-81	Gasket & Diaphragm Kit	1	4.74
GND-82	Gasket & Diaphragm Kit	1	5.74
GND-83	Gasket & Diaphragm Kit	1	6.50
GND-84	Gasket & Diaphragm Kit		
GND-86	Gasket & Diaphragm Kit	1	6.50
GND-87	Gasket & Diaphragm Kit	1	6.70
GND-88	Gasket & Diaphragm Kit		
GND-89	Gasket & Diaphragm Kit	1	6.50
GND-9	Gasket & Diaphragm Kit	1	6.50
GND-90	Gasket & Diaphragm Kit	1	6.50
GND-91	Gasket & Diaphragm Kit		
GND-92	Gasket & Diaphragm Kit	1	6.50
GND-93	Gasket & Diaphragm Kit	1	6.75
GND-94	Gasket & Diaphragm Kit	1	6.50
GND-95	Gasket & Diaphragm Kit	1	6.54
GND-96	Gasket & Diaphragm Kit	1	6.50
GND-97	Gasket & Diaphragm Kit	1	6.54
GND-98	Gasket & Diaphragm Kit		
GND-99	Gasket & Diaphragm Kit		

K005001	Plug Kit, Jet	1	4.41
K011023	Shaft, Kit Throttle	1	4.65
K011024	Shaft, Kit Throttle	1	4.65
K011025	Shaft, Kit Throttle	1	5.07
K011026	Shaft, Kit Throttle	1	4.65
K011027	Shaft, Kit Throttle	1	1.83
K011028	Shaft, Kit Throttle	1	1.83
K011093	Shaft, Kit Throttle	1	4.65
K011701	Shaft, Kit Throttle	1	4.65
K012002	Lever Kit, Throttle	1	4.70
K012015	Lever Kit, Throttle		
K017001	Cover Kit, Pump	1	8.61
K017002	Cover Kit, Pump	1	8.61
K017006	Cover Kit, Pump		
K017008	Cover Kit, Pump		
K017010	Cover Kit, Pump	1	8.61
K017012	Cover Kit, Pump		
K017014	Cover Kit, Pump	1	8.61
K017015	Cover Kit, Pump	1	8.61
K017016	Cover Kit, Pump		
K017017	Cover Kit, Pump	1	8.61
K017019	Cover Kit, Pump	1	8.61
K017021	Cover Kit, Pump	1	8.61
K017024	Cover Kit, Pump	1	8.61
K017025	Cover Kit, Pump	1	8.61
K017027	Discontinued		
K017028	Cover Kit, Pump	1	8.61
K017030	Cover Kit, Pump	1	8.61
K017034	Cover Kit, Pump	1	8.61
K017036	Cover Kit, Pump	1	8.61
K017037	Cover Kit, Pump	1	8.61
K017039	Cover Kit, Pump	1	8.61
K017040	Cover Kit, Pump	1	8.61
K017041	Cover Kit, Pump	1	8.61
K017042	Cover Kit, Pump	1	8.61
K017062	Cover Kit, Pump	1	8.61
K017064	Cover Kit, Pump	1	8.61
K017065	Cover Kit, Pump	1	8.61
K017066	Cover Kit, Pump	1	8.61
K017067	Cover Kit, Pump	1	8.61
K017068	Cover Kit, Pump	1	8.61
K017069	Cover Kit, Pump		
K017070	Cover Kit, Pump	1	8.61

K017071	Cover Kit, Pump	1	8.61
K017072	Cover Kit, Pump	1	8.61
K017073	Cover Kit, Pump	1	8.61
K017074	Cover Kit, Pump	1	8.61
K017075	Cover Kit, Pump		
K017076	Cover Kit, Pump	1	8.61
K017078	Cover Kit, Pump		
K017079	Cover Kit, Pump	1	8.61
K017080	Cover Kit, Pump	1	8.61
K017081	Cover Kit, Pump	1	8.61
K017082	Cover Kit, Pump	1	8.61
K017083	Cover Kit, Pump		
K017084	Cover Kit, Pump	1	8.61
K017085	Cover Kit, Pump	1	8.61
K017086	Cover Kit, Pump		
K017087	Cover Kit, Pump		
K017088	Cover Kit, Pump	1	8.61
K017089	Cover Kit, Pump		
K017091	Cover Kit, Pump	1	8.61
K017094	Cover Kit, Pump		
K017095	Cover Kit, Pump		
K017096	Cover Kit, Pump	1	8.61
K017701	Cover Kit, Pump	1	8.61
K030097	Screw Kit, Main Mixture	1	4.43
K030138	Screw Kit, Main Mixture	1	5.07
K030141	Screw Kit, Main Mixture	1	4.43
K030146	Screw Kit, Main Mixture	1	5.69
K030147	Screw Kit, Main Mixture	1	5.07
K031088	Screw Kit, Idle Mixture	1	5.07
K031094	Screw Kit, Idle Mixture	1	5.07
K031097	Screw Kit, Idle Mixture	1	5.07
K031098	Screw Kit, Idle Mixture	1	5.68
K031103	Screw Kit, Idle Mixture	1	5.68
K031109	Screw Kit, Idle Mixture	1	5.45
K031132	Screw Kit, Idle Mixture	1	5.07
K031135	Screw Kit, Idle Mixture	1	5.07
K031137	Screw Kit, Idle Mixture	1	5.07
K031138	Screw Kit, Idle Mixture	1	2.75
K031139	Screw Kit, Idle Mixture	1	5.45
K031141	Screw Kit, Idle Mixture	1	5.69
K031142	Screw Kit, Idle Mixture	1	5.07
K031145	Screw Kit, Idle Mixture	1	5.45
K031147	Screw Kit, Idle Mixture	1	5.07

K031148	Screw Kit, Idle Mixture	1	5.69
K031149	Screw Kit, Idle Mixture	1	5.69
K031151	Screw Kit, Idle Mixture	1	5.69
K031152	Screw Kit, Idle Mixture	1	5.69
K041001	Kit, Choke	1	6.59
K041002	Kit, Choke	1	7.32
K041003	Kit, Choke	1	6.59
K041021B	Choke Shaft Kit	1	8.52
K049001	Cover Kit, Starter Pump	1	8.85
K049002	Body Kit, Starter Pump	1	8.85
K049003	Body Kit, Pump		
K049004	Body Kit, Starter Pump	1	8.85
K049005	Body Kit, Pump		
K049006	Body Kit, Pump		
K049007	Body Kit, Pump		
K049008	Body Kit, Pump		
K053002	Plunger Kit	1	3.19
K053003	Plunger Kit	1	3.19
K053005	Plunger Kit	1	8.76
K053011	Plunger Kit	1	2.73
K053014	Plunger Kit	1	8.76
K053030	Plunger Kit	1	4.23
K053031	Plunger Kit	1	4.23
K053034	Plunger Kit	1	4.23
K053039	Plunger Kit	1	4.23
K053042	Plunger Kit	1	4.23
K053054	Plunger Kit	1	4.23
K053057	Plunger Kit	1	4.23
K053059	Plunger Kit	1	4.23
K056003	Base Kit, Primer	1	15.82
K056005	Base Kit, Primer	1	15.82
K056006	Base Kit, Primer	1	15.82
K056028	Base Kit, Primer	1	15.82
K056029	Base Kit, Primer	1	15.82
K056030	Base Kit, Primer	1	15.82
K056031	Base Kit, Primer	1	15.83
K056032	Base Kit, Primer	1	15.83
K056033	Base Kit, Primer	1	15.82
K056034	Base Kit, Primer	1	15.82
K056035	Base Kit, Primer	1	15.82
K056036	Base Kit, Primer	1	15.82
K056037	Base Kit, Primer	1	15.82
K056038	Base Kit, Primer	1	15.82

K056039	Base Kit, Primer	1	15.82
K056041	Primer Kit, External	1	15.83
K056042	Base Kit, Primer	1	15.83
K056043	Base Kit, Primer	1	15.83
K056044	Primer Kit, External	1	15.83
K056045	Primer Kit, External	1	15.83
K056046	Base Kit, Primer	1	15.83
K056047	Base Kit, Primer	1	15.83
K056048	Base Kit, Primer	1	15.83
K056701	Base Kit, Primer	1	15.83
K056703	Primer Kit, External	1	15.83
K056704	Base Kit, Primer	1	15.83
K061001	Limit Cap/Retainer Kit	1	3.52
K061002	Limit Cap/Retainer Kit	1	3.52
K088001	Body Kit, Airhead		
K088002	Body Kit, Airhead		
K088003	Body Kit, Airhead		
K088004	Body Kit, Airhead		
KS017030	Cover Kit, Pump	1	4.02
KS017031	Cover Kit, Pump	1	4.83
KS017032	Cover Kit, Pump	1	7.13
KS017045	Cover Kit, Pump	1	4.83
LA-S168	Carburetor		
LA-S6, A	Use LA-S6A	1	92.79
LA-S8, A	Use LA-S8A		
LB-S9, A	Use LB-S9A		
LCR KIT	Limit Cap/Retainer Kit	1	67.56
LE-H53	Carburetor	1	55.11
LE-H54, A	Discontinued		
LE-H56	Carburetor	1	49.90
M1-M7	Carburetor	1	45.67
RB-1	Rebuild Kit	1	9.21
RB-10	Rebuild Kit	1	10.08
RB-100	Rebuild Kit	1	9.61
RB-101	Rebuild Kit	1	11.32
RB-102	Rebuild Kit	1	9.61
RB-103	Rebuild Kit	1	10.37
RB-104	Rebuild Kit	1	9.61
RB-105	Rebuild Kit	1	10.10
RB-106	Rebuild Kit	1	10.08
RB-107	Rebuild Kit	1	10.87
RB-108	Rebuild Kit	1	10.08
RB-109	Rebuild Kit	1	10.08

RB-11	Rebuild Kit	1	8.86
RB-110	Rebuild Kit	1	10.37
RB-111	Rebuild Kit	1	9.17
RB-112	Rebuild Kit	1	11.30
RB-113	Rebuild Kit	1	9.50
RB-114	Rebuild Kit	1	10.74
RB-115	Rebuild Kit	1	9.69
RB-116	Rebuild Kit	1	9.61
RB-117	Rebuild Kit	1	9.61
RB-118	Rebuild Kit	1	10.37
RB-119	Rebuild Kit	1	10.37
RB-12	Rebuild Kit	1	8.86
RB-120	Rebuild Kit	1	10.37
RB-121	Rebuild Kit	1	10.08
RB-122	Rebuild Kit	1	10.08
RB-123	Rebuild Kit	1	10.87
RB-124	Rebuild Kit	1	10.10
RB-125	Rebuild Kit	1	10.08
RB-127	Rebuild Kit	1	10.08
RB-128	Rebuild Kit	1	10.87
RB-129	Rebuild Kit	1	10.37
RB-13	Rebuild Kit	1	8.86
RB-130	Rebuild Kit	1	10.37
RB-132	Rebuild Kit	1	10.08
RB-133	Rebuild Kit	1	16.67
RB-134	Rebuild Kit	1	10.74
RB-135	Rebuild Kit	1	10.66
RB-136	Rebuild Kit	1	10.08
RB-137	Rebuild Kit	1	10.74
RB-138	Rebuild Kit	1	10.74
RB-139	Rebuild Kit	1	10.87
RB-14	Rebuild Kit	1	8.86
RB-141	Rebuild Kit	1	10.37
RB-142	Rebuild Kit	1	10.74
RB-144	Rebuild Kit	1	10.37
RB-145	Rebuild Kit	1	10.25
RB-146	Rebuild Kit	1	10.37
RB-147	Rebuild Kit	1	10.87
RB-148	Rebuild Kit	1	10.74
RB-149	Rebuild Kit	1	10.87
RB-15	Rebuild Kit	1	9.21
RB-150	Rebuild Kit	1	10.87
RB-151	Rebuild Kit		

RB-152	Rebuild Kit	1	10.87
RB-153	Rebuild Kit	1	10.74
RB-154	Rebuild Kit	1	11.20
RB-155	Rebuild Kit		
RB-156	Rebuild Kit	1	10.74
RB-157	Rebuild Kit	1	10.87
RB-158	Rebuild Kit	1	10.87
RB-159	Rebuild Kit	1	10.74
RB-16	Rebuild Kit	1	10.71
RB-160	Rebuild Kit		
RB-161	Rebuild Kit	1	10.87
RB-162	Rebuild Kit	1	10.87
RB-163	Rebuild Kit	1	10.87
RB-164	Rebuild Kit		
RB-165	Rebuild Kit	1	11.30
RB-166	Rebuild Kit	1	10.87
RB-167	Rebuild Kit	1	10.87
RB-168	Rebuild Kit	1	11.30
RB-169	Rebuild Kit		
RB-17	Rebuild Kit	1	10.71
RB-170	Rebuild Kit		
Rb-171	Rebuild Kit		
RB-172	Rebuild Kit		
RB-173	Rebuild Kit		
RB-176	Rebuild Kit		
RB-177	Rebuild Kit	1	16.67
RB-180	Rebuild Kit		
RB-181	Rebuild Kit	1	11.32
RB-184	Rebuild Kit	1	10.87
RB-188	Rebuild Kit	1	11.30
RB-2	Rebuild Kit	1	10.08
RB-20	Rebuild Kit	1	9.76
RB-21	Rebuild Kit	1	9.21
RB-23	Rebuild Kit	1	9.21
RB-25	Rebuild Kit	1	9.21
RB-26	Rebuild Kit	1	9.21
RB-27	Rebuild Kit	1	9.21
RB-28	Rebuild Kit	1	9.21
RB-29	Rebuild Kit	1	8.86
RB-3	Rebuild Kit	1	10.08
RB-30	Rebuild Kit	1	9.21
RB-31	Rebuild Kit	1	10.08
RB-32	Rebuild Kit	1	10.08

RB-35	Rebuild Kit	1	8.86
RB-36	Rebuild Kit	1	8.86
RB-37	Rebuild Kit	1	9.21
RB-38	Rebuild Kit	1	9.21
RB-39	Rebuild Kit	1	8.86
RB-4	Rebuild Kit	1	9.21
RB-40	Rebuild Kit	1	8.86
RB-41	Rebuild Kit	1	8.86
RB-42	Rebuild Kit	1	10.74
RB-43	Rebuild Kit	1	9.21
RB-44	Rebuild Kit	1	9.21
RB-45	Rebuild Kit	1	9.21
RB-46	Rebuild Kit	1	9.21
RB-47	Rebuild Kit	1	10.78
RB-48	Rebuild Kit	1	9.21
RB-5	Rebuild Kit	1	10.08
RB-50	Rebuild Kit	1	9.21
RB-51	Rebuild Kit	1	9.21
RB-52	Rebuild Kit	1	11.77
RB-53	Rebuild Kit	1	9.21
RB-54	Rebuild Kit	1	9.21
RB-55	Rebuild Kit	1	9.21
RB-56	Rebuild Kit	1	9.21
RB-57	Rebuild Kit	1	9.21
RB-59	Rebuild Kit	1	10.08
RB-6	Rebuild Kit	1	9.21
RB-60	Rebuild Kit	1	9.76
RB-61	Rebuild Kit	1	10.08
RB-62	Rebuild Kit	1	9.21
RB-63	Rebuild Kit	1	9.21
RB-64	Rebuild Kit	1	10.08
RB-65	Rebuild Kit	1	8.86
RB-66	Rebuild Kit	1	9.21
RB-68	Rebuild Kit	1	10.08
RB-69	Rebuild Kit	1	9.76
RB-7	Rebuild Kit	1	9.21
RB-70	Rebuild Kit	1	10.08
RB-71	Rebuild Kit	1	10.08
RB-72	Rebuild Kit	1	9.21
RB-73	Rebuild Kit	1	9.66
RB-74	Rebuild Kit	1	10.08
RB-75	Rebuild Kit	1	9.59
RB-76	Rebuild Kit	1	10.08

RB-77	Rebuild Kit	1	10.08
RB-78	Rebuild Kit	1	10.08
RB-79	Rebuild Kit	1	9.69
RB-8	Rebuild Kit	1	9.21
RB-81	Rebuild Kit	1	10.32
RB-82	Rebuild Kit	1	9.21
RB-83	Rebuild Kit	1	9.69
RB-84	Rebuild Kit	1	9.21
RB-85	Rebuild Kit	1	9.69
RB-86	Rebuild Kit	1	10.35
RB-88	Rebuild Kit	1	11.30
RB-89	Rebuild Kit	1	9.21
RB-9	Rebuild Kit	1	9.21
RB-91	Rebuild Kit	1	10.10
RB-93	Rebuild Kit	1	10.10
RB-94	Rebuild Kit	1	10.08
RB-95	Rebuild Kit	1	10.10
RB-96	Rebuild Kit	1	9.17
RB-97	Rebuild Kit	1	10.10
RB-98	Rebuild Kit	1	10.08
RB-99	Rebuild Kit	1	10.08
RB-FA1	Carburetor	1	65.73
RB-FR2, A	Use RB-FR2A	1	54.87
RB-FR3, A	Use RB-FR3A	1	65.81
RB-FR4	Carburetor	1	55.50
RB-JF1	Carburetor	1	43.06
RB-K101	Carburetor with Plug	1	51.24
RB-K106	Carburetor with Plug	1	53.10
RB-K57, A-B	Use RB-K57B	1	44.17
RB-K60, A	Use RB-K60A	1	53.84
RB-K61, A	Use RB-K61A	1	53.84
RB-K63	Carburetor	1	61.41
RB-K65, A	Use RB-K65A	1	52.59
RB-K66, A-B	Use RB-K66B	1	49.83
RB-K67, A-B	Use RB-K67B	1	54.00
RB-K70, A	Use RB-K70A	1	52.37
RB-K71	Carburetor with Plug	1	55.50
RB-K72	Carburetor with Plug	1	56.67
RB-K75	Carburetor with Plug	1	58.72
RB-K84	Carburetor with 2 Plugs	1	51.56
RB-K85	Carburetor	1	51.79
RB-K86	Carburetor with Plug	1	50.76
RB-K87	Carburetor with Plug	1	50.97

RB-K88	Carburetor with Plug	1	47.44
RB-K89	Carburetor w/ 2 Plugs	1	57.90
RB-K90	Carburetor with Plug	1	52.13
RB-K91	Carburetor with Plug	1	50.04
RB-K92	Carburetor with Plug	1	52.34
RB-K93	Carburetor with Plug	1	47.44
RB-K94	Carburetor with Plug	1	50.90
RB-P25	Carburetor with Plug	1	42.67
RB-SK18, A	Use RB-SK18A	1	55.50
RC1-M45	Carburetor	1	45.19
RC1-M46	Carburetor	1	46.83
RC2-M47	Carburetor	1	50.04
RC2-M48	Carburetor	1	46.43
SVCMAN	Parts & Service Manual	1	12.01
ZF-1	In-Tank Fuel Filter	10	1.23
ZF-1/25	In-Tank Fuel Filter	25	24.98
ZF-1/50	In-Tank Fuel Filter	50	44.96
ZF-1C	In-Tank Fuel Filter	1	17.16
ZF-2	In-Tank Fuel Filter	10	1.23
ZF-2/25	In-Tank Fuel Filter	25	24.98
ZF-2/50	In-Tank Fuel Filter	50	44.96
ZF-2C	In-Tank Fuel Filter	1	17.16
ZF-3	In-Tank Fuel Filter	10	2.84
ZF-3/25	In-Tank Fuel Filter	25	70.97
ZF-3C	In-Tank Fuel Filter	1	35.48
ZF-4	In-Tank Fuel Filter	10	2.84
ZF-4/25	In-Tank Fuel Filter	25	70.97
ZF-4C	In-Tank Fuel Filter	1	35.48
ZF-5	In-Tank Fuel Filter	10	2.84
ZF-5/25	In-Tank Fuel Filter	25	70.97
ZF-5C	In-Tank Fuel Filter	1	35.48
ZGA-001	In-Tank Gasket Kit	1	81.00
ZPG-2	Pressure Gauge 15 PSI	1	69.15
ZT-1	Metering Lever Hgt Gauge	1	3.50
ZTK-101	Tool Kit	1	31.66